

Submit 3 Copies To Appropriate District  
Office  
District I  
1625 N. French Dr., Hobbs, NM 88240  
District II  
1301 W. Grand Ave., Artesia, NM 88210  
District III  
1000 Rio Brazos Rd., Aztec, NM 87410  
District IV  
1220 S. St. Francis Dr., Santa Fe, NM  
87505

State of New Mexico  
Energy, Minerals and Natural Resources

Form C-103  
Revised March 25, 1999

OIL CONSERVATION DIVISION  
1220 South St. Francis Dr.  
Santa Fe, NM 87505

WELL API NO. <b>30-025-22730</b>
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. <b>E-2519</b>
7. Lease Name or Unit Agreement Name: <b>East E-K Queen Unit</b>
8. Well No. <b>9</b>
9. Pool name or Wildcat <b>E-K Queen; East</b>

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:  
Oil Well ☐ Gas Well ☒ Other ☐ **Injection**

2. Name of Operator  
**Kevin O. Butler & Associates**

3. Address of Operator  
**P. O. Box 1171 Midland, TX 79702**

4. Well Location  
Unit Letter **E** **1650** feet from the **North** line and **330** feet from the **West** line  
Section **23** Township **18S** Range **34E** NMPM County **Lea**

10. Elevation (Show whether DR, RKB, RT, GR, etc.)  
**4000 G.L.**

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

- PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
- TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
- PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐
- OTHER: ☐

SUBSEQUENT REPORT OF:

- REMEDIAL WORK ☐ ALTERING CASING ☐
- COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
- CASING TEST AND CEMENT JOB ☐
- OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation.

1) MIRU. RIH w/ 2 7/8" tubing work string and tag cement retainer at 4369 ft. Spot cement plug on retainer from 4369 to 4269 ft. ( 6.8 sxs cement ) This plug must be tagged.

2) Spot mud from 4269 to 2374 ft. ( 30.1 bbls )

→ SPOT 100' CEMENT PLUG F/3178' to 3078' (BASE OF SALT)

3) Spot 25 sxs cement plug from 2374 to 2005 ft. ( 50 ft. above Top of Salt @ 2055 ft. )

4) Spot mud from 2005 to 455 ft. ( 24.6 bbls )

Well must be in compliance with Rule 201 by 11/11/02.

Continued on next page

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE W. G. Webb TITLE Operations Manager DATE 9-09-2002

Type or print name W. G. Webb Telephone No. 915-682-1178

(This space for State use)

APPROVED BY Gary W. Wink  
Conditions of approval, if any:

ORIGINAL SIGNED BY

GARY W. WINK

OC FIELD REPRESENTATIVE


SEP 12 2002

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPROVED.

12) continued

- 5) POOH w/ tbg. RIH and cut the 4 ½ “ production casing at 455 ft. ( this is 50’ below the 8 5/8” casing shoe at 405 ft. ) POOH w/ 455 ft. of production casing.
- 6) RIH w/ 2 7/8” workstring to 455 ft. Spot cement plug from 455 ft. to surface ( 123 sxs cmt. ).
- 7) Cut casing 8 5/8” surface casing 3 ft. below ground level.
- 8) Regulatory marker must be set in cement over wellbore.

P&A Wellbore Diagram  
East E-K Queen #.



by: WGW