

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE*
(Other instruction
verse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC 032233 - (A)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Bowers "A" Fed. Com.

9. WELL NO.

33

10. FIELD AND POOL, OR WILDCAT

Hobbs GB/SA & Blinbry

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

S29, T18S, R38E

12. COUNTY OR PARISH

Iea

13. STATE

New Mexico

1.

OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Humble Oil & Refining Company

3. ADDRESS OF OPERATOR

P.O. Box 1600, Midland, Texas 79701

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

800' FNL, 660' FWL, Sec. 29, T18S R38E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, CR, etc.)

3657' DF

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

(Other) ☐

PULL OR ALTER CASING ☐

MULTIPLE COMPLETE ☐

ABANDON* ☒

CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other) ☐

REPAIRING WELL ☐

ALTERING CASING ☐

ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

PROCEDURE:

Notify USGS, OCC and offset operators of intent to plug and abandon.

1. Displace 7" casing with gelled mud (25 sacks gel in 100 barrels produced water).
2. Spot 100' cement plug at 3960'.
3. Cut and pull 7" casing.
4. Cut and pull 9 5/8" casing. Spot 100' cement plug in casing or top of anhydrite at 1400', whichever is higher.
5. Spot 100' cement plug at 13 3/8" casing shoe.
6. Spot 20' cement plug at surface.
7. Rig wellhead for abandonment and install marker.

NOTE: Follow each cement plug with gelled mud.

18. I hereby certify that the foregoing is true and correct

SIGNED

B.M. Erdley

(This space for Federal or State office use)

TITLE District Superintendent

DATE

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

APPROVED

1972

*See Instructions on Reverse Side