

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE
(Other instructions
verse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC-032233-(a)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

BOWERS "A" FEDERAL

9. WELL NO.

32

10. FIELD AND POOL, OR WILDCAT

Hobbs, Blinebry-Drinkard

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 30, T-18-S, R38E

12. COUNTY OR PARISH

LEA,

13. STATE
N.M.

1.

OIL WELL ☐ GAS WELL ☒ OTHER

2. NAME OF OPERATOR

HUMBLE OIL & REFINING COMPANY

3. ADDRESS OF OPERATOR

P. O. BOX 1600, MIDLAND, TEXAS 79701

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

330' FSL, 1980' FEL, Sec. 30, Blk.

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3646' GR

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Circulate both casing strings with mud laden fluid.
2. Tag plug in East String at 6300' and spot 100' cement. Pull to 5800' and spot 100' plug. Pull to 4050' and spot 100' cement.
3. Tag plug in West string @ 5794' and spot 100' cement. Pull to 4050' and spot 100' cement.
4. Cut 3 1/2" at 2700'. Pull 1 string. Spot 100' plug in 9-5/8" casing at stubs and pull other string.
5. Cut and pull 9-5/8" from 1800'.
6. Run tubing and spot 100' cement at 1400'. Pull to 13-3/8" shoe at 401' and spot 100' plug across shoe.
7. Spot 20' cement in top. Cut off head and install marker.

Plugged 9-14-72

NOTE: All plugs displaced with mud laden fluid.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Manager P & A Division

DATE 9-18-72

THE POOL COMPANY

(This space for Federal or State office use)

APPROVED BY

TITLE

APPROVED

CONDITIONS OF APPROVAL, IF ANY:

JAN 12 1973

*See Instructions on Reverse Side

J. L. GORDON
Acting District Engineer