

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
E-1356	

<p align="center"><b>SUNDRY NOTICES AND REPORTS ON WELLS</b></p> <p align="center"><small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT - A" (FORM C-101) FOR SUCH PROPOSALS.)</small></p>		
1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name	
2. Name of Operator Koch Exploration Company	8. Farm or Lease Name Pennzoil Koch "B"	
3. Address of Operator P.O. Box 2256, Wichita, KS 67201	9. Well No. 2	
4. Location of Well UNIT LETTER <u>F</u> <u>2035</u> FEET FROM THE <u>N</u> LINE AND <u>1980</u> FEET FROM THE <u>W</u> LINE, SECTION <u>4</u> TOWNSHIP <u>17S</u> RANGE <u>34E</u> N.M.P.M.	10. Field and Pool, or Wildcat Vacuum/Grayburg	
15. Elevation (Show whether DF, RT, GR, etc.) 4106 KB	12. County Lea	

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Chemical cut 2-3/8" tbg off @ 10,300'
2. Ran & set CIBP w/2-3/8" tbg @ 9570'. Spot 10 sx cmt on CIBP w/top of cmt @ 9500'
3. Circ. hole to surface w/mud
4. Chemical cut 4-1/2" csg off @ 3730' & lay same down.
5. Ran tbg to 3790' & spot 50 sx cmt plug.
6. Tag top of cmt plug @ 3640'.
7. Chemical cut 8-5/8" csg off @ 1050' & lay same down.
8. Ran 2-3/8" tbg & spot 75 sx cmt plug @ 1092'
9. Tag top of cmt plug @ 912'
10. Pull tbg up to 384' & spot 75 sx cmt plug.
11. Ran tbg tag top of cmt plug @ 296' (51') up inside of 13-3/8" surf csg.
12. Set 10 sx cmt plug in top of 13-3/8" surf csg w/regulation dry hole marker.

Well P & A 1/28/85

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Vernon J. Lowe TITLE Operations Manager DATE 3/1/85

APPROVED BY JOHNNY ROBINSON TITLE CH & GAS INSPECTOR DATE SEP 2 - 1985

CONDITIONS OF APPROVAL IF ANY: