

UNIT STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE  
(Other instructions on  
reverse side)

Form approved.  
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

N.M. 04591

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Mobil Oil Corporation

3. ADDRESS OF OPERATOR

Three Greenway Plaza East, Suite 800, Houston, Texas 77046

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.\*  
See also space 17 below.)  
At surface

Unit E, 1450' FNL & 70' FWL, Sec. 19, T-18-S, R-34-E

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

E. K. Queen Unit Tr. 6

9. WELL NO.

17

10. FIELD AND POOL, OR WILDCAT

E. K. Yates 7/Rivers Queen

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA

Sec. 19, T-18-S, R-34-E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3965 GR

12. COUNTY OR PARISH

Lea

13. STATE

N. M.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

☐  
☐  
☐  
☐

PULL OR ALTER CASING

☐  
☐  
☒  
☐

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON\*

REPAIR WELL

CHANGE PLANS

(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

☐  
☐  
☐  
☐

REPAIRING WELL

☐  
☐  
☐  
☐

FRACTURE TREATMENT

ALTERING CASING

SHOOTING OR ACIDIZING

ABANDONMENT\*

(Other)

(NOTE: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

1. Run 5½" cement retainer on tubing to 4300'± and squeeze Queen perms (4368-4410') with 100 sx Class "H" neat cement.
2. Pull out of retainer and spot 5 sx neat cement on top of retainer.
3. Load hole with 9.5#/gal fluid.
4. Pull tubing to 3050'± and spot 25 sx Class "H" neat cement.
5. Pull tubing to 1750'± and spot 25 sx Class "H" neat cement.
6. Pull tubing and set 10 sx surface plug with Class "H" neat cement.
7. Erect monument and clear location.

NOTE: Verbal approval for U.S.G.S.

18. I hereby certify that the foregoing is true and correct

SIGNED

*[Signature]*

TITLE

Authorized Agent

DATE

1-3-77

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

APPROVED  
AS AMENDED

JAN 14 1976

BERNARD MOROZ

SENG DISTRICT ENGINEER

\*See Instructions on Reverse Side