DISTRIBUTION		Form C-103
		Supersedes Old C-102 and C-103
SANTA FE	NEW MEXICO OIL CONSERVATION COMMISSION	Effective 1-1-65
FILE		
U.S.G.S.		5a. Indicate Type of Lease
LAND OFFICE		State X Fee
OPERATOR		5. State Oil & Gas Lease No.
	· · · · · · · · · · · · · · · · · · ·	B-2516
SUNDR	Y NOTICES AND REPORTS ON WELLS oposals to orill or to deepen or plug back to a different reservoir. ion for permit -" (form C-101) for such proposals.)	
die GAN DY HER- Dry hole		7. Unit Agreement Name SMGSAU
2. Name of Operator		8. Farm or Lease Name
Cities Service Oil Company		Tract 7
2. Address of Operator		9. Well No.
lox 4906 - Midland, Texa	as 79701	7
, Location of Well		10. Field and Pool, or Wildcat
UNIT LETTER 1	.00 FEET FROM THE South LINE AND 1430 FEET FROM	Maljamar (G-SA)
East		
THE UINE, SECTIO	DN TOWNSHIP RANGE NMP	
///////////////////////////////////////	15. Elevation (Show whether DF, RT, GR, etc.)	12. County
	4064' DF	Lea
	Appropriate Box To Indicate Nature of Notice, Report or C TENTION TO: SUBSEQUER	Other Data NT REPORT OF:
PERFORM REMEDIAL WORK	PLUG AND ABANDON X REMEDIAL WORK	ALTERING CASING
TEMPORARILY ABANDON	COMMENCE DRILLING OPNS.	PLUG AND ABANDONMENT
PULL OR ALTER CASING	CHANGE PLANS CASING TEST AND CEMENT JOB	PLUG AND ABANDONMENT
		L
UTHER.		
17. Describe Proposed or Completed Op work) SEE RULE 1103. We pr	perations (Clearly state all pertinent details, and give pertinent dates, includin opose to plug and abandon the above well in th	ng estimated date of starting any proposed e following manner:
work) SEE RULE 1103. WE pr	opose to plug and abandon the above well in th	ng estimated date of starting any proposed e following manner:
. MIRU pulling unit and	opose to plug and abandon the above well in th d load hole with mud laden fluid.	ng estimated date of starting any proposed e following manner:
MIRU pulling unit and Pull tubing and set a	opose to plug and abandon the above well in th d load hole with mud laden fluid. a CIBP @ approx. 4260'.	ng estimated date of starting any proposed e following manner:
 MIRU pulling unit and Pull tubing and set a Dump 5 sacks cement p 	opose to plug and abandon the above well in th d load hole with mud laden fluid. a CIBP @ approx. 4260'. plug (est. 40') on top of CIBP.	ng estimated date of starting any proposed e following manner:
 MIRU pulling unit and Pull tubing and set a Dump 5 sacks cement p Cut and pull approx. 	opose to plug and abandon the above well in th d load hole with mud laden fluid. a CIBP @ approx. 4260'. plug (est. 40') on top of CIBP. 1700' of 5-1/2" csg.	e following manner:
 MIRU pulling unit and Pull tubing and set i Dump 5 sacks cement j Cut and pull approx. Spot a (15 sack cement) 	opose to plug and abandon the above well in th d load hole with mud laden fluid. a CIBP @ approx. 4260'. plug (est. 40') on top of CIBP. 1700' of 5-1/2" csg. t @ approx. 1670-1730' (1/2 in and 1/2 out of	e following manner:
 MIRU pulling unit and Pull tubing and set a Dump 5 sacks cement p Cut and pull approx. Spot a (15 sack cement Spot a 40 sack cement 	opose to plug and abandon the above well in th d load hole with mud laden fluid. a CIBP @ approx. 4260'. plug (est. 40') on top of CIBP. 1700' of 5-1/2" csg. t @ approx. 1670-1730' (1/2 in and 1/2 out of . t plug across the top of the salt @ approx. 130	e following manner: 5-1/2" esg. stub @ 1700') 80-1280'.
 MIRU pulling unit and Pull tubing and set a Dump 5 sacks cement p Cut and pull approx. Spot a (15/ sack cement) Spot a 40 sack cement Spot a 30 sack cement 	opose to plug and abandon the above well in th d load hole with mud laden fluid. a CIBP @ approx. 4260'. plug (est. 40') on top of CIBP. 1700' of 5-1/2" csg. t @ approx. 1670-1730' (1/2 in and 1/2 out of t plug across the top of the salt @ approx. 133 t plug @ approx. 780-840' (1/2 in and 1/2 out of	e following manner: 5-1/2" esg. stub @ 1700') 80-1280'. of 8-5/8" esg. stub @ 810
 MIRU pulling unit and Pull tubing and set a Dump 5 sacks cement p Cut and pull approx. Spot a (15 sack cement Spot a 40 sack cement Spot a 30 sack cement Set a 10 sack cement 	opose to plug and abandon the above well in th d load hole with mud laden fluid. a CIBP @ approx. 4260'. plug (est. 40') on top of CIBP. 1700' of 5-1/2" csg. t @ approx. 1670-1730' (1/2 in and 1/2 out of t plug across the top of the salt @ approx. 133 t plug @ approx. 780-840' (1/2 in and 1/2 out of surface plug @ approx. 30-0' and install a 4"	e following manner: 5-1/2" esg. stub @ 1700') 80-1280'. of 8-5/8" esg. stub @ 810 dry hole marker.
 Work) SEE ROLE 1103. We provide the pulling unit and set at a number of the pull tubing and set at a number of the pull tubing and set at a number of the pull approx. Spot a do sack cement Spot a 40 sack cement Spot a 10 sack cement 	opose to plug and abandon the above well in th d load hole with mud laden fluid. a CIBP @ approx. 4260'. plug (est. 40') on top of CIBP. 1700' of 5-1/2" csg. t @ approx. 1670-1730' (1/2 in and 1/2 out of t plug across the top of the salt @ approx. 133 t plug @ approx. 780-840' (1/2 in and 1/2 out of surface plug @ approx. 30-0' and install a 4"	e following manner: 5-1/2" esg. stub @ 1700') 80-1280'. of 8-5/8" esg. stub @ 810 dry hole marker.
 MIRU pulling unit and Pull tubing and set a Dump 5 sacks cement p Cut and pull approx. Spot a (15 sack cement Spot a 40 sack cement Spot a 30 sack cement Set a 10 sack cement 	opose to plug and abandon the above well in th d load hole with mud laden fluid. a CIBP @ approx. 4260'. plug (est. 40') on top of CIBP. 1700' of 5-1/2" csg. t @ approx. 1670-1730' (1/2 in and 1/2 out of t plug across the top of the salt @ approx. 133 t plug @ approx. 780-840' (1/2 in and 1/2 out of	e following manner: 5-1/2" esg. stub @ 1700') 80-1280'. of 8-5/8" esg. stub @ 810 dry hole marker.
 MIRU pulling unit and Pull tubing and set a Dump 5 sacks cement f Cut and pull approx. Spot a (15 sack cement Spot a 40 sack cement Spot a 30 sack cement Set a 10 sack cement Clear location of all 	opose to plug and abandon the above well in th d load hole with mud laden fluid. a CIBP @ approx. 4260'. plug (est. 40') on top of CIBP. 1700' of 5-1/2" csg. t @ approx. 1670-1730' (1/2 in and 1/2 out of t plug across the top of the salt @ approx. 133 t plug @ approx. 780-840' (1/2 in and 1/2 out of surface plug @ approx. 30-0' and install a 4" 1 equipment and debris and notify your office is	e following manner: 5-1/2" esg. stub @ 1700') 80-1280'. of 8-5/8" esg. stub @ 810 dry hole marker.
 MIRU pulling unit and Pull tubing and set a Dump 5 sacks cement f Cut and pull approx. Spot a (15 sack cement Spot a 40 sack cement Spot a 30 sack cement Set a 10 sack cement Clear location of all 	opose to plug and abandon the above well in th d load hole with mud laden fluid. a CIBP @ approx. 4260'. plug (est. 40') on top of CIBP. 1700' of 5-1/2" csg. t @ approx. 1670-1730' (1/2 in and 1/2 out of t plug across the top of the salt @ approx. 133 t plug @ approx. 780-840' (1/2 in and 1/2 out of surface plug @ approx. 30-0' and install a 4" 1 equipment and debris and notify your office is	e following manner: 5-1/2" esg. stub @ 1700') 80-1280'. of 8-5/8" esg. stub @ 810 dry hole marker.
 MIRU pulling unit and Pull tubing and set a Dump 5 sacks cement f Cut and pull approx. Spot a (15 sack cement Spot a 40 sack cement Spot a 30 sack cement Set a 10 sack cement Clear location of all 	opose to plug and abandon the above well in th d load hole with mud laden fluid. a CIBP @ approx. 4260'. plug (est. 40') on top of CIBP. 1700' of 5-1/2" csg. t @ approx. 1670-1730' (1/2 in and 1/2 out of t plug across the top of the salt @ approx. 133 t plug @ approx. 780-840' (1/2 in and 1/2 out of surface plug @ approx. 30-0' and install a 4" 1 equipment and debris and notify your office is	e following manner: 5-1/2" esg. stub @ 1700') 80-1280'. of 8-5/8" esg. stub @ 810 dry hole marker.
 Work) SEE ROLE 1103. We provide the pulling unit and set in the pull tubing and set in the pull tubing and set in the pull approx. Cut and pull approx. Spot a (15 sack cement) Spot a 40 sack cement. Spot a 30 sack cement. Set a 10 sack cement. Clear location of all. 	opose to plug and abandon the above well in th d load hole with mud laden fluid. a CIBP @ approx. 4260'. plug (est. 40') on top of CIBP. 1700' of 5-1/2" csg. t @ approx. 1670-1730' (1/2 in and 1/2 out of t plug across the top of the salt @ approx. 133 t plug @ approx. 780-840' (1/2 in and 1/2 out of surface plug @ approx. 30-0' and install a 4" 1 equipment and debris and notify your office is	e following manner: 5-1/2" esg. stub @ 1700') 80-1280'. of 8-5/8" esg. stub @ 810 dry hole marker.
 MIRU pulling unit and Pull tubing and set a Dump 5 sacks cement f Cut and pull approx. Spot a (15 sack cement Spot a 40 sack cement Spot a 30 sack cement Set a 10 sack cement Clear location of all 	opose to plug and abandon the above well in th d load hole with mud laden fluid. a CIBP @ approx. 4260'. plug (est. 40') on top of CIBP. 1700' of 5-1/2" csg. t @ approx. 1670-1730' (1/2 in and 1/2 out of t plug across the top of the salt @ approx. 133 t plug @ approx. 780-840' (1/2 in and 1/2 out of surface plug @ approx. 30-0' and install a 4" 1 equipment and debris and notify your office is	e following manner: 5-1/2" esg. stub @ 1700') 80-1280'. of 8-5/8" esg. stub @ 810 dry hole marker.
 MIRU pulling unit and Pull tubing and set a Dump 5 sacks cement f Cut and pull approx. Spot a (15 sack cement Spot a 40 sack cement Spot a 30 sack cement Set a 10 sack cement Clear location of all 	opose to plug and abandon the above well in th d load hole with mud laden fluid. a CIBP @ approx. 4260'. plug (est. 40') on top of CIBP. 1700' of 5-1/2" csg. t @ approx. 1670-1730' (1/2 in and 1/2 out of t plug across the top of the salt @ approx. 133 t plug @ approx. 780-840' (1/2 in and 1/2 out of surface plug @ approx. 30-0' and install a 4" 1 equipment and debris and notify your office is	e following manner: 5-1/2" esg. stub @ 1700') 80-1280'. of 8-5/8" esg. stub @ 810 dry hole marker.
 MIRU pulling unit and Pull tubing and set a Dump 5 sacks cement f Cut and pull approx. Spot a (15 sack cement Spot a 40 sack cement Spot a 30 sack cement Set a 10 sack cement Clear location of all 	opose to plug and abandon the above well in th d load hole with mud laden fluid. a CIBP @ approx. 4260'. plug (est. 40') on top of CIBP. 1700' of 5-1/2" csg. t @ approx. 1670-1730' (1/2 in and 1/2 out of t plug across the top of the salt @ approx. 133 t plug @ approx. 780-840' (1/2 in and 1/2 out of surface plug @ approx. 30-0' and install a 4"	e following manner: 5-1/2" esg. stub @ 1700') 80-1280'. of 8-5/8" esg. stub @ 810 dry hole marker.
 MIRU pulling unit and Pull tubing and set a Dump 5 sacks cement f Cut and pull approx. Spot a (15 sack cement Spot a 40 sack cement Spot a 30 sack cement Set a 10 sack cement Clear location of all 	opose to plug and abandon the above well in th d load hole with mud laden fluid. a CIBP @ approx. 4260'. plug (est. 40') on top of CIBP. 1700' of 5-1/2" csg. t @ approx. 1670-1730' (1/2 in and 1/2 out of t plug across the top of the salt @ approx. 133 t plug @ approx. 780-840' (1/2 in and 1/2 out of surface plug @ approx. 30-0' and install a 4" 1 equipment and debris and notify your office is	e following manner: 5-1/2" esg. stub @ 1700') 80-1280'. of 8-5/8" esg. stub @ 810 dry hole marker.
MIRU pulling unit and Pull tubing and set a Dump 5 sacks cement p Cut and pull approx. Spot a (15 sack cement Spot a 40 sack cement Spot a 30 sack cement Clear location of all Clear location of all Clear horation of all Clear horation of all Clear horation of all MIRU pulling unit and Set a 10 sack cement Clear horation of all Clear horation horatio	opose to plug and abandon the above well in th d load hole with mud laden fluid. a CIBP @ approx. 4260'. plug (est. 40') on top of CIBP. 1700' of 5-1/2" csg. t @ approx. 1670-1730' (1/2 in and 1/2 out of t plug across the top of the salt @ approx. 133 t plug @ approx. 780-840' (1/2 in and 1/2 out of surface plug @ approx. 30-0' and install a 4" I equipment and debris and notify your office of W. M. Acce No. Acce	e following manner: 5-1/2" esg. stub @ 1700') 80-1280'. of 8-5/8" esg. stub @ 810 dry hole marker.
MIRU pulling unit and Pull tubing and set a Dump 5 sacks cement p Cut and pull approx. Spot a (15 sack cement Spot a 40 sack cement Spot a 30 sack cement Clear location of all Clear location of all Clear horation of all Clear horation of all Clear horation of all MIRU pulling unit and Set a 10 sack cement Clear horation of all Clear horation horatio	opose to plug and abandon the above well in th d load hole with mud laden fluid. a CIBP @ approx. 4260'. plug (est. 40') on top of CIBP. 1700' of 5-1/2" csg. t @ approx. 1670-1730' (1/2 in and 1/2 out of t plug across the top of the salt @ approx. 133 t plug @ approx. 780-840' (1/2 in and 1/2 out of surface plug @ approx. 30-0' and install a 4" I equipment and debris and notify your office of W. M. Acce No. Acce	e following manner: 5-1/2" esg. stub @ 1700') 80-1280'. of 8-5/8" esg. stub @ 810 dry hole marker.
MIRU pulling unit and Pull tubing and set a Dump 5 sacks cement p Cut and pull approx. Spot a (15 sack cement Spot a 40 sack cement Spot a 30 sack cement Clear location of all Clear location of all Clear horation of all Clear horation of all Clear horation of all MIRU pulling unit and Set a 10 sack cement Clear horation of all Clear horation horatio	opose to plug and abandon the above well in th d load hole with mud laden fluid. a CIBP @ approx. 4260'. plug (est. 40') on top of CIBP. 1700' of 5-1/2" csg. t @ approx. 1670-1730' (1/2 in and 1/2 out of t plug across the top of the salt @ approx. 133 t plug @ approx. 780-840' (1/2 in and 1/2 out of surface plug @ approx. 30-0' and install a 4" I equipment and debris and notify your office of W. M. Acce No. Acce	e following manner: 5-1/2" esg. stub @ 1700') 80-1280'. of 8-5/8" esg. stub @ 810 dry hole marker.
MIRU pulling unit and Pull tubing and set a Dump 5 sacks cement p Cut and pull approx. Spot a (15 sack cement Spot a 40 sack cement Spot a 30 sack cement Clear location of all	opose to plug and abandon the above well in th d load hole with mud laden fluid. a CIBP @ approx. 4260'. plug (est. 40') on top of CIBP. 1700' of 5-1/2" csg. t @ approx. 1670-1730' (1/2 in and 1/2 out of t plug across the top of the salt @ approx. 133 t plug @ approx. 780-840' (1/2 in and 1/2 out of surface plug @ approx. 30-0' and install a 4" I equipment and debris and notify your office of W. M. Acce No. Acce	e following manner: 5-1/2" esg. stub @ 1700') 80-1280'. of 8-5/8" esg. stub @ 810 dry hole marker. for final inspection.
MIRU pulling unit and Pull tubing and set a Dump 5 sacks cement p Cut and pull approx. Spot a (15 sack cement Spot a 40 sack cement Spot a 30 sack cement Clear location of all ACC	opose to plug and abandon the above well in th d load hole with mud laden fluid. a CIBP @ approx. 4260'. plug (est. 40') on top of CIBP. 1700' of 5-1/2" csg. t @ approx. 1670-1730' (1/2 in and 1/2 out of t plug across the top of the salt @ approx. 133 t plug @ approx. 780-840' (1/2 in and 1/2 out of surface plug @ approx. 30-0' and install a 4" I equipment and debris and notify your office of W. M. Acce No. Acce	e following manner: 5-1/2" esg. stub @ 1700') 80-1280'. of 8-5/8" esg. stub @ 810 dry hole marker. for final inspection.