

OIL CONSERVATION DIVISION

P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
B-1189-1	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT - 1" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER: <u>Water Injection</u>		7. Unit Agreement Name <u>Vacuum Grayburg</u>
2. Name of Operator <u>Texaco Inc.</u>		8. Farm or Lease Name <u>San Andres Unit</u>
3. Address of Operator <u>P.O.Box 728, Hobbs, New Mexico 88240</u>		9. Well No. <u>31</u>
4. Location of Well UNIT LETTER <u>J</u> <u>2630</u> FEET FROM THE <u>South</u> LINE AND <u>1330</u> FEET FROM THE <u>East</u> LINE, SECTION <u>2</u> TOWNSHIP <u>18-S</u> RANGE <u>34-E</u> N.M.P.M.		10. Field and Pool or Wildcat <u>Vacuum Grayburg</u> <u>San Andres</u>
11. Elevation (Show whether DF, RT, GR, etc.) <u>4014' (DF)</u>		12. County <u>Lea</u>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER: <u>Repair water flow</u> <input checked="" type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rig up. Install BOP. Pull tubing & pkr.
2. Set RBP @ 4500' & dump 20' of sand on plug.
3. Perforate 4 1/2" Csg w/2-JS @ 1675'.
4. Set cement retainer @ 1575'. Cement to surface through perfs. @ 1675' w/450 sx class 'H' cement. WOC DOC Test. Pull RBP.
5. Run injection equipment. Return to water injection.

THE COMPLETION MUST BE NOTIFIED
24 HOURS PRIOR TO ANY FURTHER WORK

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED: <u>[Signature]</u>	TITLE: <u>Asst. Dist. Mgr.</u>	DATE: <u>12-2-81</u>
APPROVED BY: <u>[Signature]</u>	TITLE: _____	DATE: <u>DEC 7 1981</u>
CONDITIONS OF APPROVAL, IF ANY:		