

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

**OIL CONSERVATION DIVISION**  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO. <u>30-025-24843</u>
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. E-1632-1
7. Lease Name or Unit Agreement Name New Mexico "U" State
8. Well No. 4
9. Pool name or Wildcat E-K Queen East

<b>SUNDRY NOTICES AND REPORTS ON WELLS</b> (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	
2. Name of Operator <u>Anadarko Petroleum Corporation</u>	
3. Address of Operator <u>P. O. Drawer 130 Artesia, New Mexico 88211-0130</u>	
4. Well Location Unit Letter <u>E</u> : <u>1980</u> Feet From The <u>North</u> Line and <u>660</u> Feet From The <u>West</u> Line Section <u>28</u> Township <u>18S</u> Range <u>34E</u> NMPM Lea County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) <u>4035 GR</u>	

11.

Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

**NOTICE OF INTENTION TO:**

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐  
OTHER: ☐

**SUBSEQUENT REPORT OF:**

REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rig up pulling unit. Go in hole with tubing.
2. Circulate hole with mud laden fluid.
3. Pull up and spot 156 sacks Class C cement with 2% CaCl (1.32 cu.ft./sx yield) from 4605' up to 3063'. Trip out of hole with tubing. Note: Plug #1 covers top of Queen, 7-Rivers, Yates formation and base of salt.
4. Go in hole with casing cutter and tag top of plug. Pull up and cut off casing at approximately 3000'.
5. Trip out of hole with 5 1/2" casing.
6. Go in hole with tubing and spot 40 sacks Class C with 2% CaCl from 3050' up to 2915'. Plug #2 covers casing stub. Wait and tag top of plug.
7. Pull up and spot 40 sacks Class C with 2% CaCl from 2016' up to 1916'. Plug #3 covers top of salt. Wait and tag top of plug.
8. Pull up and spot 30 sacks Class C with 2% CaCl from 1462' up to 1362'. Plug #4 covers 8 5/8" casing stub. Wait and tag top of plug.
9. Pull up and spot 50' plug at surface. Plug #5 covers surface plug.
10. Cut off all casing and anchors below ground level. Install dry hole marker and rip location and road.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Mike Braswell TITLE Field Foreman DATE 3-12-92

TYPE OR PRINT NAME Mike Braswell TELEPHONE NO. 505-748-3368

(This space for State Use)  
ORIGINAL SIGNED BY JERRY SEXTON  
DISTRICT I SUPERVISOR

MAR 16

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: