

COPY TO O. C. G.
UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRII
(Other Instruction
verse side)

Form approved.
Budget Bureau No. 42-R1424.
5. LEASE DESIGNATION AND SERIAL NO.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. ☒ OIL WELL ☐ GAS WELL ☐ OTHER

2. NAME OF OPERATOR
PETROLEUM DEVELOPMENT CORPORATION

3. ADDRESS OF OPERATOR
9720 B Candelaria NE, Albuquerque, New Mexico 87112

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface
1980' FNL & 1980' FWL, Section 34, T18S, R32E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)
3706 GL

NM 18302

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME
McKay West Federal

9. WELL NO.
1

10. FIELD AND POOL, OR WILDCAT
Querecho Plains
Bone Springs

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA
Sec. 34, T18S, R32E

12. COUNTY OR PARISH
Lea

13. STATE
New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐
FRACTURE TREAT ☐
SHOOT OR ACIDIZE ☐
REPAIR WELL ☐
(Other) ☐ Proposed Cherry Canyon (Delaware) completion

PULL OR ALTER CASING ☐
MULTIPLE COMPLETE ☐
ABANDON* ☐
CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐
FRACTURE TREATMENT ☐
SHOOTING OR ACIDIZING ☐
(Other) ☐

REPAIRING WELL ☐
ALTERING CASING ☐
ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Note: Present production from Bone Spring formation is about 3 barrels oil per day. Reservoir is limited and nearly depleted.

1. MI & RUPU & BOP. Pull rods and pump; release tubing anchor (15,000# tension), pull tubing, lay down 33 joints.
2. Run tubing with CIBP; set CIBP @ 8600'. Lay down 2-7/8" tubing. Dump 35' cement on top of BP.
3. Perforate 4904-4918 with 4 jspf.
4. Run 2-3/8" tubing; MA & SN. Spot and treat with 500 gallons 7½% MCA. Swab and test.
5. Fracture treat if need is indicated.
6. Place well on pump.

RECEIVED

FEB 15 1979

U. S. GEOLOGICAL SURVEY
HOBBS, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED Charles W. Sanders TITLE Vice President

(This space for Federal or State office use)

APPROVED BY _____ TITLE _____
CONDITIONS OF APPROVAL, IF ANY:

APPROVED
FEB 15 1979
ACTING DISTRICT ENGINEER

*See Instructions on Reverse Side