

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 1004-0135
Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL NO.

LC 069726 069276

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1.

OIL WELL ☐ GAS WELL ☒ OTHER

2. NAME OF OPERATOR

Robert N. Enfield

3. ADDRESS OF OPERATOR

P. O. Box 2431, Santa Fe, New Mexico 87501

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*

See also space 17 below.)
At surface

660' FNL & 1980' FWL of Sec. 30

Unit C-

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3784.4 GR

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Hudson Federal

9. WELL NO.

2

10. FIELD AND POOL, OR WILDCAT

Unders. Sec. Corbin Morrow Geo

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

Sec. 30, T-18-S, R-33-E

12. COUNTY OR PARISH

Lea

13. STATE

N.M.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

FRACTURE TREAT

MULTIPLE COMPLETION

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANE

(Other) Work well over as stated

XX

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

General Procedure

1. Move-in & rig-up workover equipment.
2. Set a CIBP at 12,000' KB; dump 50 feet of cement on top.
3. Perforate with 2 shots per foot from 11,104' to 11,118' KB.
4. Acidize; flow/swab to test.
5. Set on RBP at 11,050' KB.
6. Perforate from 10,947' to 10,969' & 10,986' to 11,000' KB.
7. Acidize; flow/swab to test.
8. Kill well; release packer, latch onto RBP and POH.
9. Install completion assembly.
10. Run potential test and initiate production.

Work is to begin as soon as approved.

18. I hereby certify that the foregoing is true and correct

SIGNED

James P. Corbin

TITLE Agent for Robert N. Enfield

DATE 3/11/92

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE 3/23/92

CONDITIONS OF APPROVAL, IF ANY: