

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYCOPY TO O. C. C.
SUBMIT IN THIS FORM
(Other instructions on reverse side)Form approved.
Budget Bureau No. 42-R1424.
5. LEASE DESIGNATION AND SERIAL NO.

NM-2843A

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER	7. UNIT AGREEMENT NAME
2. NAME OF OPERATOR INEXCO OIL COMPANY	8. FARM OR LEASE NAME Federal Com 7
3. ADDRESS OF OPERATOR Suite 1900, 1100 Milam Bldg., Houston, Texas 77002	9. WELL NO. 2
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 1980' FNL & 660' FWL	10. FIELD AND POOL, OR WILDCAT West Tonto Penn
14. PERMIT NO.	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 7, T-19S, R-33E
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3659.4	12. COUNTY OR PARISH Lea
	13. STATE New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐

(Other)

PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☐CHANGE PLANS ☐

Recomplete in Strawn

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐

(Other)

REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Inexco proposes to set an Otis "PN" plug in the "N" nipple at \pm 13,150' and test to 5000 psi, then set a CIBP at 13,100' and set a 50' plug in top of CIBP. Perforate with 2 SPF 12,398-12,400 for squeeze then perforate 12,270-12,272 to block squeeze above and below the Strawn. Run CBL 12,360-12,100, then perforate 12,318-12,327 with 2 SPF (18 holes) to attempt completion in the Strawn.

There will be no new surface disturbance.

RECEIVED

APR 18 1980

U. S. GEOLOGICAL SURVEY
HOBBS, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED

K.C. Maddy

TITLE Drlg. Administrator

DATE 4/15/80

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE APR 24 1980

*See Instructions on Reverse Side