

STATE "AP" WELL NO. 1  
UNDESIGNATED DRINKARD  
LEA COUNTY, NEW MEXICO

CONTINUATION FROM FORM C-101

7. Release packer, retrieve RBP and set RBP @ 7220'; set packer @ 7065'; load hole w/2% KCL water.
8. Acidize perfs 7087'-7168' w/2500 gallons 15% NEA @ 1 BPM and maximum pressure of 2000 PSI, flush tubing and SI 1 hour.
9. Swab test perfs @ 7087'-7168'.
10. Release packer, retrieve RBP & set RBP @ 7065', set packer @ 7000'. Load hole w/2% KCL water.
11. Acidize perfs @ 7046'-47' w/500 gallons 15% NEA at 1 BPM and maximum pressure of 2000 PSI. Flush tubing and SI 1 hour.
12. Swab test perfs @ 7046'-47'.
13. If excess water is not obtained, release packer, retrieve RBP, return to production and test.