

CONDITIONS OF APPROVAL, IF ANY:

- 8). Spot a 25 sx plug from 3000'-3100' with class "C" cmt.
- 9). Spot a 25 sx plug from 1462'-1715' with class "C" cmt.
- 10). Perforate two squeeze holes at 368'. Establish rate through squeeze holes. Pump class "C" cmt down 5 1/2" csg until circulated to surface (estimated 85 sx).
- 11). Cut off wellhead. Install dry hole marker. Clean location.

2000 111

112 100