

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION

P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease
State ☐ Fee ☒

5. State Oil & Gas Lease No.
30-025-2638

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- 2. Name of Operator Anadarko Production Company 3. Address of Operator P.O. Box 806 Eunice, New Mexico 88231 4. Location of Well UNIT LETTER F, 2310 FEET FROM THE North LINE AND 2310 FEET FROM THE West LINE, SECTION 29 TOWNSHIP 18S RANGE 39E NMPM. 15. Elevation (Show whether DF, RT, GR, etc.) 3587.7	7. Unit Agreement Name 8. Farm or Lease Name June Speight 9. Well No. 1 10. Field and Pool, or Wildcat East Hobbs 12. County Lea
---	--

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. TIH w/2-3/8" tubing, 10-16-81. With tubing @ 5980', set 10 sx Class C cement plug w/2% CACL & 1/4# Flocele. WOC 4 hrs. Tag plug. Top of plug should be @approx. 5840'.
2. Mud up w/61 bbls of 10# brine & 21 sx brine gel.
3. With tubing @4520', set 8 sx Class H cement plug 50' below & 50' above top of SA.
4. Free point & cut 4 1/2" csg @approx 2100'. Pull 4 1/2" csg.
5. With tubing 50' in 4 1/2" csg stub, mud up w/134 bbls of 10# brine & 47 sx brine gel.
6. With tubing 50' in 4 1/2" csg stub, pump 105 sx Class H cement plug. Top of plug will be 50' in 8-5/8" csg. @1805'.
7. Cut off 8-5/8" below plow depth. Set 10 sx Class H cement plug & weld on plate. As requested by surface holder, no plugged hole marker will be set.

THE COMMISSION MUST BE NOTIFIED
24 HOURS PRIOR TO COMMENCING WORK

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED John C. English TITLE Area Supervisor DATE October 15, 1981

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY: