

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-7

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.B.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease
State ☒ Fee ☐
5. State Oil & Gas Lease No.
B-1113-1

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐
2. Name of Operator
TEXACO, Inc.
3. Address of Operator
P. O. Box 728, Hobbs, New Mexico 88240
4. Location of Well
UNIT LETTER L 2196 FEET FROM THE South LINE AND 525 FEET FROM
THE West LINE, SECTION 6 TOWNSHIP 18-S RANGE 35-E NMPM.

7. Unit Agreement Name
Central Vacuum Unit
8. Farm or Lease Name
Central Vacuum Unit
9. Well No.
153
10. Field and Pool, or Wildcat
Vacuum Grayburg
San Andres

15. Elevation (Show whether DF, RT, GR, etc.)
3982' (GR)

12. County
Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:
PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐
OTHER Addl Perfs in San Andres ☒
SUBSEQUENT REPORT OF:
REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOBS ☐
OTHER ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. RIG UP. PULL RODS AND PUMP. INSTALL BOP. PULL TUBING.
2. DRILL OUT CEMENT RETAINER AND CLEAN OUT TO 4726'.
3. INSTALL PUMPING EQUIPMENT. TEST PRODUCTION.
4. SET CEMENT RETAINER @ 4615'. SQUEEZE PERFORATIONS 4627-4697' W/200 SX CLASS H CEMENT. WOC. DOC. TEST.
5. PERFORATE 5 1/2" CSG W/2-JSPF @ 4244, 53, 63, 67, 4309, 12, 14, 17, 23, 24, 26, 44, & 4350'.
6. SET RBP @ 4615' AND PKR @ 4482'. ACIDIZE PERFS 4497-4604' W/400 GALS 20% NEFE ACID IN 3-STAGES USING 150# ROCK SALT BETWEEN STAGES. FLUSH W/1200 GALS 2% KCL WATER.
7. RESET RBP @ 4482' AND PKR @ 4374'. ACIDIZE PERFS 4383-4468' W/2400 GALS 20% NEFE ACID IN 3-STAGES USING 100# ROCK SALT BETWEEN STAGES. FLUSH W/1150 GALS 2% KCL WATER.
8. RESET RBP @ 4374' AND PKR @ 4150'. ACIDIZE PERFS 4244-4367' W/3600 GALS 20% NEFE ACID IN 3-STAGES USING 50# ROCK SALT AND 5-BALL SEALERS BETWEEN STAGES. FLUSH W/1225 GALS 2% KCL WATER. PULL PKR AND RBP.
9. INSTALL PUMPING EQUIPMENT. TEST AND RETURN TO PRODUCTION.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE District Operations Manager DATE 12-19-84

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT 1 SUPERVISOR
APPROVED BY _____ TITLE _____ DATE DEC 20 1984

CONDITIONS OF APPROVAL, IF ANY: