Ferm 3160-5 (November 1983) (Formerly 9-331)	UNITED STATES DEPARTME OF THE INTERI		Form approved. Budget Bureau No. 1004-0135 Expires August 31, 1985 5. LEASE DESIGNATION AND SERIAL NO
SUNDRY NOTICES AND REPORTS ON WELLS (1) o not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT—" for such proposals.)			6. IF INDIAN, ALLOTTEE OR TRIBE NAME
OIL X GAS OTHER			7. UNIT AGREEMENT NAME
2. NAME OF OPERATOR			8. FARM OR LEASE NAME
V-F PETROLEUM INC. 3. ADDRESS OF OPERATOR			UNCLE SAM 25 FEDERAL COM 9. WELL NO.
ONE MARIENFELD PLACE, SIE 580 MIDLAND, TX 79701 1. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface			1 10. FIELD AND POOL, OR WILDCAT QUERECHO PLAINS U. BONE SPR- 11. SEC. T., B., M., OR BLE. AND CURRENT
1980' FSL & 660' FWL			SEC. 25 T-18-S R-32-E
14. PERMIT NO. 15 ELEVATIONS (Show whether DF, RT, GR, etc.)			12. COUNTY OR PARISH 13. STATE
30-025-284	140		LEA NEW MEXICO
16.	Check Appropriate Box To Indicate N	lature of Notice Report or C	ther Data
NOTICE OF INTENTION TO: 80BSEQUENT REPORT OF:			
TEST WATER SHUT-OFF PCLL OR ALTER UNSING WATER SHUT-OFF BEPAIRING WELL PRACTURE TREAT MULTIPLE COMPLETE SHOOT OR ACIDIZE ABANDON* SHOOTING OR ACIDIZING ABANDONMENT* (Other) Other) TEST STRAWN FORMATION (NOTE: Report results of multiple completion on Well Completion or Recompletion or Recompletion Report and Log form.) 17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clenity state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) WELL IS CURRENTLY PRODUCING FROM BONE SPRING FORMATION @ APPROX. 2 BOPD, 8 MCFGPD, 22 BWP			
PLAN TO SQUEE AND PRODUCTION	EZE THE BONE SPRING PERFS, DRIL	L CEMENT & CEMENT RETA THIS WELL WILL BE PLAC	AINER, CLEAN OUT WELLBORE CED IN THE SOUTH CORBIN
PROCEDURE:			
2. INSTALL BO 3. SQUEEZE BO 4. DRILL OUT 5. PERFORATE	TOH W/ ALL PRODUCTION EQUIPMEN OP & TEST TO 2000# FOR 30 MINUT ONE SPRING PERFS 8604' - 8644'. CEMENT & CEMENT RETAINER & TES & PRODUCTION TEST STRAWN POROS LL TO PRODUCTION.	ES. T 5 1/2" CASING TO 200	DO# FOR 30 MINUTFS.
			ÂUG CAR ARC
			~ ~~
			TH.
			₩ ¥
18. I hereby certify tha	t the foregoing is true and correct		<u> </u>
signedKENNETH	11 12 11	LOGIST/ENG. TECH.	8/19/93
APPROVED BY	PPROVAL, IF ANY:	A STATE OF THE STA	DATE