

Submit 3 Copies
to Appropriate
District Office

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

WELL API NO. 30-025-28790
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. LG-3425
7. Lease Name or Unit Agreement Name Compton State
8. Well No. 1
9. Pool name or Wildcat Airstrip Bone Springs
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3984.5' GR

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator YATES PETROLEUM CORPORATION
3. Address of Operator 105 South Fourth Street - Artesia, NM 88210
4. Well Location Unit Letter <u>C</u> : <u>330</u> Feet From The <u>North</u> Line and <u>1980</u> Feet From The <u>West</u> Line Section <u>35</u> Township <u>18S</u> Range <u>34E</u> NMPM Lea County

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103. NOTE: NOTIFY OCD (393-6161) 24 HOURS PRIOR TO COMMENCING OPERATIONS.
Propose to plug and abandon well as follows:

- Nipple up BOP. POOH with production string.
- Set CIBP at 9100' and cap with 35' of cement to abandon Bone Springs perforations.
- Fill hole with 10.0 ppg salt gel containing 25# gel/barrel of water.
- Determine free point of 5-1/2" production casing. Cut and pull as much casing as possible. CBL indicates top of cement at 7188'.
- Spot 50 sack cement plug (150' plug in open hole) on top of 5-1/2" casing stub. Tag plug.
- Spot 50 sack cement plug from 5370-5220' to cover top of San Andres at 5302'. Tag plug.
- Spot 50 sack cement plug from 4100-3940' to cover intermediate casing shoe at 3995'. Tag plug.
- Spot 30 sack cement plug from 460-350' across surface casing shoe at 405'.
- Spot 15 sack cement plug from 55' to surface.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Rusty Klein TITLE Production Clerk DATE 7-11-94
TYPE OR PRINT NAME Rusty Klein TELEPHONE NO. 505-748-1471

(This space for State Use) ORIGINAL FILED BY _____ DATE _____
APPROVED BY _____ TITLE _____ DATE _____

JUL 14 1994