

Form 3160-5
(June 1990)

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

MERIDIAN OIL INC.

3. Address and Telephone No.

P.O. Box 51810 Midland, TX 79710

915-688-6800

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

455' FNL & 2310' FEL

SEC. 20, T-18-S, R-33-E

FORM APPROVED

Budget Bureau No. 1004-0135

Expires: March 31, 1993

5. Lease Designation and Serial No.

NM-616044

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No. SOUTH CORBIN

FEDERAL # 1

9. API Well No.

30-025-29536

10. Field and Pool, or Exploratory Area

CORBIN (YATES)

11. County or Parish, State
LEA COUNTY, NM

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other
☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

1. POOH w/ 2-3/8" tbg. GIH w/ gauge ring on 2-3/8" tbg to 9500'. Circulate hole w/ 10 ppg gelled brine mud. POOH w/ tbg and gauge ring.

2. RU wireline company and packoff. GIH 5-1/2" CIBP and set @ 7300'. Cap w/ 30' cement.

3. RIH w/ 5-1/2" CIBP on 2-3/8" tbg setting CIBP @ 4920'. Squeeze perfs 4967'-75' w/ 100 sx Class C cement. Cap CIBP w/ 6 sx (60') cement. POOH w/ tbg.

4. GIH w/ 5-1/2" CIBP on 2-3/8" tbg setting CIBP @ 3000'. Spot 25 sx (253') Class C cement on top.

5. Pick up tbg to +/- 1575'. Spot 25 sx (253') Class C cement plug.

6. Pick up tbg to +/- 430'. Spot 25 sx (253') Class C cement plug.

7. Pick up tbg to +/- 101'. Spot 10 sx (101') Class C cement plug to surface.

8. Cut off casing 3' below ground level. Weld steel plate and abandonment marker on top. Clean location.

14. I hereby certify that the foregoing is true and correct

Signed

[Signature]

DOUGLAS WILLIAMS

Title PRODUCTION ASSISTANT

Date

9/2/94

(This space for use by the Bureau of Land Management)

(ORIG. SGD.) JOE G. LARA

Approved by

Title

PETROLEUM ENGINEER

Date

9/9/94

Conditions of approval, if any:

See attached