



# United States Department of the Interior

BUREAU OF LAND MANAGEMENT

Roswell District Office

SPECIAL APPROVAL STIPULATIONS

IN REPLY REFER TO

*Murphy Operating*  
*South Corbin Fed.*  
*#1*

THE FOLLOWING DATA IS REQUIRED ON THE WELL SIGN

MURPHY OPERATING CORPORATION  
South Corbin Federal No. 1  
NW $\frac{1}{4}$ NE $\frac{1}{4}$ , Sec. 20, T. 18 S., R. 33 E.  
Lea County  
NM-61604

The special stipulations check marked below are applicable to the above described well and approval of this application to drill is conditioned upon compliance with such stipulations in addition to the general requirements. EACH PERMITTEE HAS THE RIGHT OF ADMINISTRATIVE APPEAL TO THESE STIPULATIONS PURSUANT TO TITLE 43 CFR 3165.3 and 3165.4.

☒ 1. The Bureau of Land Management office is to be notified at:

- ☐ (505) 624-1790 Roswell  
☒ (505) 897-6544 Carlsbad  
☒ (505) 393-3612 Hobbs

in sufficient time for a representative to witness:

- ☒ 1. Spudding  
☒ 2. Cementing  
13  $\frac{3}{8}$  inch  
8  $\frac{5}{8}$  inch  
inch  
☒ 3. WFT Tests

*Capitan water basin*

☒ 4. At least one working day prior to constructing the well pad, access roads and/or related facilities, the operator or dirt contractor shall notify the authorized officer of the surface management agency. The surface management agency may be contacted at:

- ☒ BLM phone (505) 897-6544, Carlsbad, New Mexico  
☒ BLM phone (505) 624-1790, Roswell, New Mexico

He shall also notify the surface management agency within two working days after completion of earth-moving activities.

☒ 5. Roads in the area of operations of this authorization will require surfacing.

*13  $\frac{3}{8}$ "* casing should be set in the Austin Anhydrite formation and cemented to the surface. The casing should be cemented to the surface through a plug set in place 20 feet above the top of the Permian after cementing around the shoe with grout. (1388')  
*8  $\frac{5}{8}$ "* casing should be set in the Permian formation and cemented to the surface through a plug set in place 20 feet above the top of the Permian after cementing around the shoe with grout. (2740')

☒ 6. The operator shall ensure the casing is set in the Permian formation and cemented to the surface through a plug set in place 20 feet above the top of the Permian after cementing around the shoe with grout.

☒ 7. The operator shall ensure the casing is set in the Permian formation and cemented to the surface through a plug set in place 20 feet above the top of the Permian after cementing around the shoe with grout.

☒ 8. After setting the casing string and before drilling into the Wolfcamp formation, the blowout preventers and related control equipment failing to test satisfactorily shall be repaired or replaced. This office should be notified in sufficient time for a representative to witness the tests and shall be furnished a copy of the pressure test report.

☒ 9. The operator shall ensure the casing is set in the Permian formation and cemented to the surface through a plug set in place 20 feet above the top of the Permian after cementing around the shoe with grout.