

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Geology, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO.	30-025-30108
5. Indicate Type of Lease	STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.	B1482
7. Lease Name or Unit Agreement Name	Foran NF State (See attached schematic)
8. Well No.	1
9. Pool name or Wildcat	Lusk Delaware

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	
2. Name of Operator Foran Oil Company	
3. Address of Operator 8340 Meadow Road, Suite 158, Dallas, Texas 75231	
4. Well Location Unit Letter B : 330 Feet From The North Line and 1980 Feet From The East Line Section 32 Township 19S Range 32E NMPM Lea County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3549' GL	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

MIRU PU (reverse cir.), pull rods & tubing, set CIBP @ 5560' on WL & cap w/35' cement. Pressure test BP and if OK mud up using 10#/gal brine + 25# gel/bbl. Run free point and cut-off 5-1/2" casing @ 3900' or where free. Set 100' (25+ sx) cement plug, 50' below and 50' above 5-1/2" stub. Set 100' (25+ sx) cement plug @ 890' inside 8-5/8" csg. Set 10 sx surface cement plug and set dry-hole marker.

WILL NEED TO PULL OR SET 8 5/8" CSG @ 890'

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Les M. Carnes TITLE Executive Vice President DATE 7-25-90

TYPE OR PRINT NAME Les M. Carnes TELEPHONE NO. (806) 376-

(This space for State Use) ORIGINAL BY STATE OF NEW MEXICO
DEPARTMENT OF GEOLOGY

APPROVED BY _____ TITLE _____

CONDITIONS OF APPROVAL, IF ANY:

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPROVED.