

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-30133-0000
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. E-9721

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Lease Name or Unit Agreement Name New Mexico "CR" State
2. Name of Operator Texaco Inc.	8. Well No. 4
3. Address of Operator P.O. Box 730, Hobbs, NM 88240	9. Pool name or Wildcat Lusk Delaware, West
4. Well Location Unit Letter <u>C</u> : <u>330</u> Feet From The <u>North</u> Line and <u>1662</u> Feet From The <u>West</u> Line Section <u>32</u> Township <u>19S</u> Range <u>32E</u> NMPM Lea County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3540' GL	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data			
NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>		CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER: <input type="checkbox"/>		OTHER: <input type="checkbox"/>	

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1) Inform BLM 24 hrs. prior to commencement of work.
- 2) MIRU pulling unit. Install BOP.
- 3) TIH with workstring to PBTD 2440'. Load hole with salt gel mud consisting of 10 lb. brine with 25 lbs. of gel per barrel.
- 4) Spot a 30 sx plug of Class "C" cement (1.32 cuft/sx) from 2440'-2150' (base of salt 2150'). Tag plug.
- 5) Pull up and spot a 25 sx plug of Class "C" cement (1.32 cuft/sx) from 1060'-810' (top of salt 1059', surface casing shoe 950'). Tag plug.
- 6) Pull up and pump 6 sx of Class "C" cement (1.32 cuft/sx) from 50'-surface.
- 7) Cut off wellhead. Install marker. Clean location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE [Signature] TITLE Area Manager DATE 10-4-90

TYPE OR PRINT NAME _____ TELEPHONE NO. _____

(This space for State Use)

ORIGINAL FILED BY CLARY SEXTON

APPROVED BY [Signature] TITLE _____ DATE OCT 08 1990

CONDITIONS OF APPROVAL, IF ANY:

ALL INFORMATION MUST BE PROVIDED TO THE BUREAU OF LAND MANAGEMENT FOR THE RECORDS OF THE STATE OF NEW MEXICO.