

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-77

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease
State ☐ Fee ☒

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-	7. Unit Agreement Name
2. Name of Operator Primary Fuels, Inc.	8. Farm or Lease Name Harvard
3. Address of Operator 415 W. Wall, Suite 1300, Midland, TX 79701	9. Well No. 1
4. Location of Well UNIT LETTER N 330' FEET FROM THE south LINE AND 1980' FEET FROM THE west LINE, SECTION 31 TOWNSHIP 18S RANGE 39E NMPM.	10. Field and Pool, or Wildcat Foster (San Andres)
15. Elevation (Show whether DF, RT, GR, etc.) 3604.5 GL	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Set a cast iron bridge plug at 4,400'± and cap with 50 ft. of cement (7 sacks)
- Load the hole with mud-laden fluid.
- Shoot off the 5-1/2" casing at 3,000'± and pull out of the hole.
100' PLUG 1/2" IN 1/2" OUT OF CSG STUB
- Run tubing to 385' and spot a 100' cement plug across the bottom of the 8-5/8" surface casing.
- Pull the tubing to 50' and place a cement plug (18 sacks) from 50' to the surface.
- Cut off the casing and mark as required by State rules.
- Clean location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Fred Rad TITLE Engineer DATE 7/25/88

APPROVED BY CHIEF OF DIVISION TITLE CHIEF OF DIVISION DATE JUL 28 '88
CONDITIONS OF APPROVAL, IF ANY: