

2. Protective Equipment for Essential Personnel:

Mark II Surviveair 30 minute unit or equivalent located at briefing area as indicated on wellsite diagram.

3. H2S Detection and Monitoring Equipment:

Two portable H2S monitors positioned on location for best coverage and response. These units have audible sirens when H2S levels of 20 ppm are reached.

4. Visual Warning Systems:

- A. Wind direction indicators as shown on well site diagram.
- B. Caution/Danger signs will be posted on roads providing direct access to location. Signs will be painted a high visibility color with lettering of sufficient size to be readable at reasonable distance from the immediate location.

5. Mud Program:

The mud program has been designed to minimize the volume of H2S circulated to the surface. Proper mud weight, safe drilling practices, and the use of H2S scavengers will minimize hazards while drilling the well.

6. Metallurgy:

All drill strings, casings, tubing, wellhead, blowout preventors, drilling spools, kill lines choke manifold and lines, and valves shall be suitable for H2S service when chemically treated.

7. Communications:

Communications in company vehicles and toolpushers vehicle may be cellular telephone or two way radio.

8. Well Testing:

Drill Stem testing is anticipated in this well. It will be conducted with a minimum number of personnel in the immediate vicinity which are necessary to conduct the test. The test will be conducted during daylight hours only.