

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs NM 88241-1980

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION

2040 Pacheco St.
Santa Fe, NM 87505

WELL API NO.
30-025-36011

5. Indicate Type of Lease
STATE ☐ FEE ☒

6. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:
OIL WELL ☒ GAS WELL ☐ OTHER

2. Name of Operator
Occidental Permian Limited Partnership

3. Address of Operator
P.O. Box 4294, Houston, TX 77210-4294

4. Well Location
SHL: Unit Letter K : 2114 Feet From The South Line and 1568 Feet From The West Line
BHL: K 2385 South 1549 West
Section 29/32 Township 18-S Range 38-E NMPM Lea County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)
3645' GL

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: Run 7" Casing <input checked="" type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

11/6/02 -

11/9/02: Run 125 jts. 7", 23#, J-55, LT&C casing with 40 Spiralglide centralizers x 6 tandem rise bow centralizers and set at 4049' TVD (5161' MD). Pump first stage cement with 350 sx. Premium Plus. Plug down. Inflate ECP x open DV tool. Circulate 42 sx. cement off DV tool. Pump second stage cement with 1000 sx. Interfill 'C' x 100 sx. Premium Plus. Plug down x circulate 480 sx. to surface. ND BOP x set casing slips x cut off 7" casing. NU BOP and test blind rams, manifold, and casing to 1400 psi x 30 min. Run 6-1/8" bit x drill out DV tool. Test pipe rams x casing to 1400 psi x 30 min. Drill out cement x circulate hole clean. Commence control drilling (for horizontal hole) at 5000' TMD.

11/16/02 -

11/18/02 - Log lateral section and tag TD at 7037' (MD).
Release drilling rig @ 12:00 p.m., 11/18/02

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Mark Stephens TITLE Business Analyst (SG) DATE 11/21/02

TYPE OR PRINT NAME Mark Stephens TELEPHONE NO. 281/552-1158

(This space for State Use) ORIGINAL SIGNED BY

CHRIS WILLIAMS

OC DISTRICT SUPERVISOR/GENERAL MANAGER

APPROVED BY _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY:

DEC 03 2002