

OIL CONSERVATION DIVISION

P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-79

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
B-1056	

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		7. Unit Agreement Name
2. Name of Operator		Central Vacuum Unit
3. Address of Operator		8. Farm or Lease Name
P. O. Box 728, Hobbs, New Mexico 88240		Central Vacuum Unit
4. Location of Well		9. Well No.
UNIT LETTER 0 660 FEET FROM THE South LINE AND 1980 FEET FROM		37
East 25 TOWNSHIP 17-S RANGE 34-E N.M.P.M.		10. Field or Pool or Wildcat
THE LINE, SECTION TOWNSHIP RANGE N.M.P.M.		San Andres
15. Elevation (Show whether DF, RT, GR, etc.)		12. County
4007' (DF)		Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. RIGGED UP. INSTALL BOP. PULL TUBING AND SUMMERSIBLE PUMP.
2. CLEAN OUT CLEAN OUT & UNDERREAM TO 4750' (TD).
3. SET PKR @ 4000'. ACIDIZE OPENHOLE SECTION 4108'-4750' W/10,000 GALS 15% GELLED NEFE ACID IN 5-STAGES USING 500# MOTH BALLS AND 500# SALT BETWEEN STAGES. FLUSH W/100 BBLs PRODUCED WATER. PULL PKR.
4. SET RBP @ 4000' AND SPOT 20' SAND ON PLUG.
5. PERFORATE 5 1/2" CSG W/J-JSPF @ 1570'.
6. SET CEMENT RETAINER @ 1500'. CEMENT SQUEEZE PERFORATION @ 1570' W/325 SX CLASS H CEMENT CONTAINING 2% CACL & 500 GALS FLOCHEX. WOC. DOC. TESTED CASING TO 500#. TESTED OK.
7. INSTALL PRODUCTION EQUIPMENT. TEST AND PLACE ON PRODUCTION.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Ednie W. Sady</u>	TITLE <u>Asst Dist Mgr</u>	DATE <u>8-23-84</u>
APPROVED BY <u>Oil &amp; Gas Inspector</u>	TITLE	DATE
CONDITIONS OF APPROVAL, IF ANY:		

AUG 28 1984