

STATE OF NEW MEXICO  
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION  
P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
B-2341	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator	West Vacuum Unit
3. Address of Operator	8. Farm or Lease Name
P. O. Box 722, Hobbs, New Mexico 88240	West Vacuum Unit
4. Location of Well	9. Well No.
UNIT LETTER <u>I</u> , <u>4620</u> FEET FROM THE <u>North</u> LINE AND <u>660</u> FEET FROM	37
THE <u>East</u> LINE, SECTION <u>34</u> TOWNSHIP <u>17-S</u> RANGE <u>34-E</u> NMPM.	10. Field and Pool, or Wildcat
	Vacuum (Crayburg)
	San Andres
15. Elevation (Show whether DF, RT, GR, etc.)	12. County
4036' (GR)	Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER <u>Clean out &amp; Deepen in same Zone</u> <input checked="" type="checkbox"/>			

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rig up. Pull rods & pump. Install BOP. Pull tubing.
2. Fish approximately 150' Submersible pump cable between 4600'-4675'.
3. Deepen 35' to 4710'
4. Set pkr. @ 3800'. Acidize open-hole 4206'-4710' w/5000 gals. 20% stabilized gelled acid and 5000# 100-mesh sand in 2-stages, using 100# rock salt & 200# Benzoic Acid Flakes between stages. Flush well.
5. Install production equipment. Test & place on production.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Asst. Dist. Mgr. DATE 4-13-83

APPROVED BY DISTRICT I SUPERVISOR TITLE  DATE APR 15 1983

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED  
APR 14 1983  
O.C.D.  
HOBBS OFFICE