

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-10
Revised 11

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT - 1" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee
2. Name of Operator <u>TEZACO Inc.</u>	5. State Oil & Gas Lease No. <u>B-155</u>
3. Address of Operator <u>P. O. Box 728, Hobbs, New Mexico 88240</u>	7. Unit Agreement Name <u>Central Vacuum Uni</u>
4. Location of Well UNIT LETTER <u>H</u> <u>660</u> FEET FROM THE <u>East</u> LINE AND <u>1980</u> FEET FROM THE <u>North</u> LINE, SECTION <u>36</u> TOWNSHIP <u>17-S</u> RANGE <u>34-E</u> NMPM.	8. Farm or Lease Name <u>Central Vacuum Uni</u>
	9. Well No. <u>66</u>
	10. Field and Pool, or Wildcat <u>Vacuum Grayburg</u> <u>San Andres</u>
15. Elevation (Show whether DF, RT, GR, etc.) <u>4000' (GR)</u>	12. County <u>Lea</u>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <u>Repair Csg. Leak</u> <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rig up. Install BOP. Pull tubing & submersible pump.
2. Set RBP @ 3500' & spot 20' sand on plug.
3. Perforate 5 1/2" csg 7/2 JS @ 1560'.
4. Set cement retainer @ 1500'. Cement perms. @ 1560' w/250 sx. Class 'H' cement containing 2% CaCl. Circulate cement. Squeeze w/addl. 150 sx. class 'H' Cement.
5. WOC DOC & test. Pull RBP.
6. Run production equipment. Test & return to production.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>[Signature]</u>	TITLE <u>Asst. Dist. Mgr.</u>	DATE <u>6-21-83</u>
APPROVED BY <u>ORIGINAL SIGNED BY JERRY SEXTON</u>	TITLE <u>DISTRICT SUPERVISOR</u>	DATE <u>6-24-83</u>
CONDITIONS OF APPROVAL, IF ANY:		