

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
2. Name of Operator Marathon Oil Company		5. State Oil & Gas Lease No. 265
3. Address of Operator P. O. Box 2409 Hobbs, New Mexico 88240		7. Unit Agreement Name ---
4. Location of Well UNIT LETTER <u>K</u> <u>1980</u> FEET FROM THE <u>South</u> LINE AND <u>1980</u> FEET FROM THE <u>West</u> LINE, SECTION <u>30</u> TOWNSHIP <u>17-S</u> RANGE <u>35 E</u> NMPM.		8. Farm or Lease Name Staplin State A/C 1
15. Elevation (Show whether DF, RT, GR, etc.) 3998' DF		9. Well No. 2
		10. Field and Pool, or Wildcat Vacuum
		12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐  
TEMPORARILY ABANDON ☐  
PULL OR ALTER CASING ☒  
OTHER ☐

PLUG AND ABANDON ☒  
CHANGE PLANS ☐  
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐  
COMMENCE DRILLING OPNS. ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER ☐

ALTERING CASING ☐  
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Well is presently shut in with TD at 4710' and San Andres perms 4638'-4698'

Plan to:

1. Set cement retainer at 3900'(50' above liner)
2. Abandon perms with 50 sacks cement below and cap with 10 sacks above retainer
3. Cut off casing at 2420'
4. Place plug at top of 7" pipe with 25 sacks in and 25 sacks out
5. Place plug at bottom of 95/8" pipe(497') with 25 sacks in and 25 sacks out
6. Spot 10 sacks back to the surface of the 9 5/8" pipe
7. Cut off pipe 3' below surface and weld on plate

*100' plug @ top well*

All plugs will be separated by mud-laden fluid

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED

*C. L. Heltzer Jr.*

TITLE Operations Superintendent

DATE 6/28/74

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY: