

P&A PROCEDURE CENTRAL VACUUM UNIT NO. 8

- 1). MIRU PULLING UNIT, INSTALL BOP.
- 2). TIH WITH 4 1/2" CEMENT RETAINER AND TBG TO 1930' AND SET RETAINER.
- 3). ESTABLISH PUMPING RATE WITH WATER; PUMP 300 SACKS CLASS 'C' CEMENT, PULL OUT OF RETAINER AND CIRCULATE CASING WITH 10# MUD. POH.
- 4). TIH WITH CIBP AND SET AT 1600' WITH 35' CEMENT ON TOP.
- 5). TIH WITH CIBP AND SET AT 300' WITH 35' CEMENT ON TOP.
- 6). CUT WELLHEAD OFF, SET SURFACE PLUG AND P&A MARKER; RDPU, CLEAN LOCATION.