

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO.
30-025-02963

5. Indicate Type of Lease
STATE ☒ FEE ☐

6. State Oil & Gas Lease No.
A-1320

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:
OIL WELL ☒ GAS WELL ☐ OTHER

2. Name of Operator
Phillips Petroleum Company

3. Address of Operator
4001 Penbrook Street, Odessa, TX 79762

4. Well Location
Unit Letter B : 660 Feet From The North Line and 1977 Feet From The West Line
Section 32 Township 17S Range 35E NMPM Lea County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)
3962' GL; 3975' RKB

7. Lease Name or Unit Agreement Name

East Vacuum Gb/SA Unit
Tract 3202

8. Well No.
02

9. Pool name or Wildcat
Vacuum Gb/SA

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- MIRU DDU. NU Class II BOP.
- Set a 5-1/2" CICR at 4100' using 2-3/8" tubing. Squeeze with Plug No. 1 (125 sx cement) 4100'-4675'. This will cover the San Andres.
- Circulate 5-1/2" casing with 9.5 ppg mud-laden fluid. Spot Plug No. 2 (25 sx cement) 4000'-4100'. This will cover the Grayburg.
- Spot Plug No. 3 (25 sx cement) 2700'-2800'. This will cover the Yates.
- Perforate the 5-1/2" casing at 1625'. Set packer at 1400'. Squeeze with Plug No. 4 (85 sx cement) 1500'-1625'. This will cover the salt top and the 9-5/8" casing shoe. Tag Plug.
- Perforate and circulate the 5-1/2" casing with Plug NO. 5 (70 sx. cement) 3'-325' leaving the 5-1/2" casing and the 7-5/8" x 5-1/2" annulus full of cement.
- Cut off casing 3' below ground level. Install monument marker. Perform reclamation work.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE L. M. Sanders TITLE Supv. Regulatory Affairs DATE 04-29-94
TYPE OR PRINT NAME L. M. Sanders (915) TELEPHONE NO. 368-1488

(This space for State Use)

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT I SUPERVISOR

APPROVED BY _____ TITLE _____ DATE MAY 03 1994

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

MAY 12 1964

**JCS HODDS
OFFICE**