brait 3 Copies Ener Minerals and Natural Resources Depa Appropriate	artment Revised 1-1-89
ISTRICT I O. Box 1980, Hobbs, NM 88240 OIL CONSERVATION DIVIS P.O. Box 2088	SION WELL API NO. 20-025-02981
ISTRICT II O. Drawer DD, Antesia, NM \$8210 Santa Fe, New Mexico 87504-2088	S. Indicate Type of Lance STATE X FEE
ISTRICT III 200 Rio Brazos Rd., Aziec, NM 87410	6. State Oil & Gas Lease No. B-1713
SUNDRY NOTICES AND REPORTS ON WELLS	
DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BA DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	CK TO A 7. Lease Name or Unit Agreement Name East Vacuum Gb/SA Unit
Type of Well: OE GAS OTHER	Tract 3333
Name of Operator	8. Well No.
Phillips Petroleum Company	001. 9. Pool asme or Wildcat
Address of Operator 4001 Penbrook St., Odessa, Texas 79762	Vacuum Gb/SA
Well Location	
Unit Letter H: 1980_ Feet From The North Line a	nd <u>660</u> Feet From The <u>East</u> Line
	NMPM Lea County
Section 33 Township 17-S Range 35-E	INNUM Dec
3939' GL	
Check Appropriate Box to Indicate Nature of I	Notice, Report, or Other Data
	SUBSEQUENT REPORT OF:
	_
	ALTERING CASING
NOTICE OF INTENTION TO:	
	WORK ALTERING CASING CE DRILLING OPNS. PLUG AND ABANDONMENT
ERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL EMPORARILY ABANDON CHANGE PLANS COMMENCE	
ERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL EMPORARILY ABANDON CHANGE PLANS COMMENC ULL OR ALTER CASING CASING T	
ERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL EMPORARILY ABANDON CHANGE PLANS COMMENC ULL OR ALTER CASING CASING TO OTHER: Remedial	CE DRILLING OPNS. PLUG AND ABANDONMENT
ERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL EMPORARILY ABANDON CHANGE PLANS COMMENC ULL OR ALTER CASING CASING T	CE DRILLING OPNS. PLUG AND ABANDONMENT
ERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL EMPORARILY ABANDON CHANGE PLANS COMMENCE ULL OR ALTER CASING CASING CASING TO OTHER: OTHER: OTHER: THER: COMPLETE OPERations (Clearly state all periment details, and give perime work) SEE RULE 1103.	CE DRILLING OPNS. PLUG AND ABANDONMENT
ERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL EMPORARILY ABANDON CHANGE PLANS COMMENCE ULL OR ALTER CASING CASING TO CASING TO OTHER: Re-perforate and Stimulate OTHER: 12 Describe Proposed or Completed Operations (Clearly state all persistent details, and give persistent work) SEE RULE 1103. OTHER: 1. NU BOP. POOH with rods and pump. POOH with tu 2. Drill out cement at 4519' and cement retainers	CE DRILLING OPNS. PLUG AND ABANDONMENT
ERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL EMPORARILY ABANDON CHANGE PLANS COMMENCE ULL OR ALTER CASING CASING CASING TO OTHER: Re-perforate and Stimulate COMMENCE THER: Re-perforate and Stimulate COMMENCE 12 Describe Proposed or Completed Operations (Clearly state all periment details, and give perime work) SEE RULE 1103. 1. NU BOP. POOH with rods and pump. POOH with tu 2. Drill out cement at 4519' and cement retainers	CE DRILLING OPNS. PLUG AND ABANDONMENT
ERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL EMPORARILY ABANDON CHANGE PLANS COMMENC ULL OR ALTER CASING CASING TO CASING TO OTHER: Re-perforate and Stimulate CASING TO OTHER: Re-perforate and Stimulate OTHER: 12 Describe Proposed or Completed Operations (Clearly state all periment details, and give perime work) SEE RULE 1103. 1. NU BOP. POOH with rods and pump. POOH with tu 2. Drill out cement at 4519' and cement retainers cement to 4687'. Circulate hole clean. 3. Using 3-3/8" guns loaded with premium charges	CE DRILLING OPNS. PLUG AND ABANDONMENT
ERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL EMPORARILY ABANDON CHANGE PLANS COMMENCE ULL OR ALTER CASING CASING CASING TO OTHER: Re-perforate and Stimulate COMMENCE THER: Re-perforate and Stimulate COMMENCE CASING TO OTHER: COMMENCE THER: Re-perforate and Stimulate COMMENCE CASING TO OTHER: COMMENCE COMMENCE COMMENCE CASING TO OTHER: COMMENCE CASING TO OTHER: COMMENCE COMMENCE CASING TO OTHER: COMMENCE COMMENCE CASING TO OTHER: COMMENCE COMMENCE CASING TO OTHER: COMMENCE COMM	CE DRILLING OPNS. PLUG AND ABANDONMENT EST AND CEMENT JOB ns dates, including estimated date of starting any proposed ubing string. at 4575' and 4620' and remaining (2 SPF) on spiral phacing, and perfora packer at 4600'.
ERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL EMPORARILY ABANDON CHANGE PLANS COMMENC ULL OR ALTER CASING CHANGE PLANS CASING THER: OTHER: Re-perforate and Stimulate X OTHER: 12 Describe Proposed or Completed Operations (Clearly state all periment details, and give perime work) SEE RULE 1103. OTHER: 12. NU BOP. POOH with rods and pump. POOH with tu 2. Drill out cement at 4519' and cement retainers cement to 4687'. Circulate hole clean. 3. Using 3-3/8" guns loaded with premium charges the following: 4520'-4677' 185 total shots. 4. RIH with RBP and packer. Set RBP at 4680' and	CE DRILLING OPNS. PLUG AND ABANDONMENT EST AND CEMENT JOB ns dates, including estimated date of starting any proposed ubing string. at 4575' and 4620' and remaining (2 SPF) on spiral phacing, and perfora packer at 4600'. D0 gallons of 15% NEFE acid. Swab.
ERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL EMPORARILY ABANDON CHANGE PLANS COMMENC ULL OR ALTER CASING CASING T CASING T OTHER: Re-perforate and Stimulate X OTHER: 12 Describe Proposed or Completed Operations (Clearly state all periment details, and give perime work) SEE RULE 1103. OTHER: 1. NU BOP. POOH with rods and pump. POOH with tu 2. Drill out cement at 4519' and cement retainers cement to 4687'. Circulate hole clean. 3. Using 3-3/8" guns loaded with premium charges the following: 4520'-4677' 185 total shots. 4. 4. RIH with RBP and packer. Set RBP at 4680' and 5. Acidize perforated interval with a total of 210 6. Unseat packer, lower same and retrieve RBP.	CE DRILLING OPNS. PLUG AND ABANDONMENT EST AND CEMENT JOB ns dates, including estimated date of starting any proposed ubing string. at 4575' and 4620' and remaining (2 SPF) on spiral phacing, and perfora packer at 4600'. D0 gallons of 15% NEFE acid. Swab.
ERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL EMPORARILY ABANDON CHANGE PLANS COMMENC ULL OR ALTER CASING CHANGE PLANS COMMENC OTHER: Re-perforate and Stimulate CASING THER: THER: Re-perforate and Stimulate OTHER: TOTHER: Remediate CASING THER: TOTHER: Remediate CASING THER: TOTHER: Remediate COMMENC CASING THER: CASING THER: OTHER: TOTHER: Remediate CASING THER: TOTHER: Remediate COMMENC CASING THER: CASING THER: OTHER: The completed Operations (Clearly state all periment details, and give periment work) SEE RULE 1103. 1. NU BOP. POOH with rods and pump. POOH with the Clean. 3. Using 3-3/8" guns loaded with premium charges the following: 4520'-4677' 185 total shots. 4. RIH with RBP and packer. Set RBP at 4680' and 5. Acidize perforated interval with a total of 210 G. 6. Unseat packer, lower same and retrieve RBP. PON DDD to 1000 pein	CE DRILLING OPNS. PLUG AND ABANDONMENT EST AND CEMENT JOB na dates, including estimated date of starting any proposed bling string. at 4575' and 4620' and remaining (2 SPF) on spiral phacing, and perform packer at 4600'. 00 gallons of 15% NEFE acid. Swab. ull RBP to 4625' and set same. Test
ERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL EMPORARILY ABANDON CHANGE PLANS COMMENC ULL OR ALTER CASING CHANGE PLANS CASING THER: THER: Re-perforate and Stimulate X OTHER: 12 Describe Proposed or Completed Operations (Clearly state all periment details, and give periment work) SEE RULE 1103. OTHER: 12. NU BOP. POOH with rods and pump. POOH with tu 2. Drill out cement at 4519' and cement retainers cement to 4687'. Circulate hole clean. 3. Using 3-3/8" guns loaded with premium charges the following: 4520'-4677' 185 total shots. 4. RIH with RBP and packer. Set RBP at 4680' and 5. Acidize perforated interval with a total of 210 Unseat packer, lower same and retrieve RBP. 6. Unseat packer, lower same and retrieve RBP. PURRP to 1000 psi. 7. Acidize perforated interval with a total of 650'. PUI packer to 4350'.	CE DRILLING OPNS. PLUG AND ABANDONMENT EST AND CEMENT JOB na dates, including estimated date of starting any proposed bling string. at 4575' and 4620' and remaining (2 SPF) on spiral phacing, and perfora packer at 4600'. 00 gallons of 15% NEFE acid. Swab. ull RBP to 4625' and set same. Test
ERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL EMPORARILY ABANDON CHANGE PLANS COMMENC ULL OR ALTER CASING CASING CASING THER: THER: Re-perforate and Stimulate CASING THER: TIL Describe Proposed or Completed Operations (Clearly state all performent details, and give performe work) OTHER: 12 Describe Proposed or Completed Operations (Clearly state all performent details, and give performe work) SEE RULE 1103. 1. NU BOP. POOH with rods and pump. POOH with tu 2. Drill out cement at 4519' and cement retainers cement to 4687'. Circulate hole clean. 3. Using 3-3/8" guns loaded with premium charges the following: 4520'-4677' 185 total shots. 4. RIH with RBP and packer. Set RBP at 4680' and 5. Acidize perforated interval with a total of 210 Gunseat packer, lower same and retrieve RBP. 6. Unseat packer, lower same and retrieve RBP. Printer RBP to 1000 psi. 7. Acidize perforated interval with a total of 50 8. LE haver partice are to be kept open, then:	CE DRILLING OPNS. PLUG AND ABANDONMENT EST AND CEMENT JOB nu dates, including estimated date of starting any proposed ubing string. at 4575' and 4620' and remaining (2 SPF) on spiral phacing, and perfora packer at 4600'. 00 gallons of 15% NEFE acid. Swab. ull RBP to 4625' and set same. Test 00 gallons of 15% NEFE acid. Swab. Ower RBP to 4680' and pull packer
ERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL EMPORARILY ABANDON CHANGE PLANS COMMENS ULL OR ALTER CASING CASING CASING TO OTHER: Re-perforate and Stimulate X OTHER: 12 Describe Proposed or Completed Operations (Clearly sale all periment details, and give perimet work) SEE RULE 1103. OTHER: 12. NU BOP. POOH with rods and pump. POOH with tu 2. Drill out cement at 4519' and cement retainers cement to 4687'. Circulate hole clean. 3. Using 3-3/8" guns loaded with premium charges the following: 4520'-4677' 185 total shots. A. 4. RIH with RBP and packer. Set RBP at 4680' and 5. Acidize perforated interval with a total of 210 G. 6. Unseat packer, lower same and retrieve RBP. Pr 7. Acidize perforated interval with a total of 650 A: 8. Unseat packer, lower same and retrieve RBP. Pr 8. Unseat packer, lower same and retrieve RBP. Lower same and retrieve RBP.	CE DRILLING OPNS. PLUG AND ABANDONMENT EST AND CEMENT JOB ns dates, including estimated date of starting any proposed ubing string. at 4575' and 4620' and remaining (2 SPF) on spiral phacing, and perform packer at 4600'. 00 gallons of 15% NEFE acid. Swab. ull RBP to 4625' and set same. Test 00 gallons of 15% NEFE acid. Swab. Ower RBP to 4680' and pull packer
 ERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL EMPORARILY ABANDON CHANGE PLANS COMMENS COMMENS ULL OR ALTER CASING CASING THER: Re-perforate and Stimulate CASING THER: THER: Re-perforate and Stimulate OTHER: I2 Describe Proposed or Completed Operations (Clearly state all periment details, and give periment work) SEE RULE 1103. NU BOP. POOH with rods and pump. POOH with the 2. Drill out cement at 4519' and cement retainers cement to 4687'. Circulate hole clean. Using 3-3/8" guns loaded with premium charges the following: 4520'-4677' 185 total shots. RIH with RBP and packer. Set RBP at 4680' and Acidize perforated interval with a total of 210 Unseat packer, lower same and retrieve RBP. Pr RBP to 1000 psi. Pull packer to 4350'. Acidize perforated interval with a total of 650 A: If lower perfs are to be kept open, then: 8A. Unseat packer, lower same and retrieve RBP. Laback to 4350' and set same. 	CE DRILLING OPNS. PLUG AND ABANDONMENT EST AND CEMENT JOB nu dates, including estimated date of starting any proposed ubing string. at 4575' and 4620' and remaining (2 SPF) on spiral phacing, and perform packer at 4600'. 00 gallons of 15% NEFE acid. Swab. ull RBP to 4625' and set same. Test 00 gallons of 15% NEFE acid. Swab. Ower RBP to 4680' and pull packer
ERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL EMPORARILY ABANDON CHANGE PLANS COMMENCE ULL OR ALTER CASING CASING T CASING T OTHER: Re-perforate and Stimulate IX OTHER: 12 Describe Proposed or Completed Operations (Clearly state all periment details, and give perime work) SEE RULE 1103. OTHER: OTHER: 12 Describe Proposed or Completed Operations (Clearly state all periment details, and give perime work) SEE RULE 1103. OTHER: OTHER: 12 Describe Proposed or Completed Operations (Clearly state all periment details, and give perime work) SEE RULE 1103. OTHER: OTHER: 13 Dirill out cement at 4519' and cement retainers cement to 4687'. Circulate hole clean. Susing 3-3/8" guns loaded with premium charges the following: 4520'-4677' 185 total shots. 4. RIH with RBP and packer. Set RBP at 4680' and Acidize perforated interval with a total of 210 6. Unseat packer, lower same and retrieve RBP. Prompted perforated interval with a total of 650 A: 7. Acidize perforated interval with a total of 650 A: 8. Unseat packer, lower same and retrieve RBP. Id back to 4350' and set same. 1. Dentity test for adding shower is the same. Lower perfect at the same.	CE DRILLING OPNS. PLUG AND ABANDONMENT EST AND CEMENT JOB na dates, including estimated date of starting any proposed abing string. at 4575' and 4620' and remaining (2 SPF) on spiral phacing, and perform packer at 4600'. 00 gallons of 15% NEFE acid. Swab. ull RBP to 4625' and set same. Test 00 gallons of 15% NEFE acid. Swab. ower RBP to 4680' and pull packer (Ov
ERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL EMPORARILY ABANDON CHANGE PLANS COMMENCE ULL OR ALTER CASING CASING T CASING T OTHER: Re-perforate and Stimulate IX OTHER: 12 Describe Proposed or Completed Operations (Clearly state all periment details, and give perime work) SEE RULE 1103. OTHER: OTHER: 12 Describe Proposed or Completed Operations (Clearly state all periment details, and give perime work) SEE RULE 1103. OTHER: OTHER: 12 Describe Proposed or Completed Operations (Clearly state all periment details, and give perime work) SEE RULE 1103. OTHER: OTHER: 13 Dirill out cement at 4519' and cement retainers cement to 4687'. Circulate hole clean. Susing 3-3/8" guns loaded with premium charges the following: 4520'-4677' 185 total shots. 4. RIH with RBP and packer. Set RBP at 4680' and Acidize perforated interval with a total of 210 6. Unseat packer, lower same and retrieve RBP. Prompted perforated interval with a total of 650 A: 7. Acidize perforated interval with a total of 650 A: 8. Unseat packer, lower same and retrieve RBP. Id back to 4350' and set same. 1. Dentity test for adding shower is the same. Lower perfect at the same.	CE DRILLING OPNS. PLUG AND ABANDONMENT EST AND CEMENT JOB ns dates, including estimated date of starting any proposed ubing string. at 4575' and 4620' and remaining (2 SPF) on spiral phacing, and perform packer at 4600'. 00 gallons of 15% NEFE acid. Swab. ull RBP to 4625' and set same. Test 00 gallons of 15% NEFE acid. Swab. Ower RBP to 4680' and pull packer
ERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL EMPORARILY ABANDON CHANGE PLANS COMMENC ULL OR ALTER CASING CASING TO CASING TO OTHER: Re-perforate and Stimulate X OTHER: 12 Describe Proposed or Completed Operations (Clearly state all periment details, and give perime work) SEE RULE 1103. OTHER: OTHER: 12 Describe Proposed or Completed Operations (Clearly state all periment details, and give perime work) SEE RULE 1103. OTHER: OTHER: 12 Describe Proposed or Completed Operations (Clearly state all periment details, and give perime work) SEE RULE 1103. OTHER: OTHER: 12 Describe Proposed or Completed Operations (Clearly state all periment details, and give perime work) SEE RULE 1103. OTHER: OTHER: 13 Divide a to Complete Operations (Clearly state all periment details, and give perime work) SEE RULE 1103. Image: Clearly state all periment details, and give perime 14 Divide a to Complete Operations (Clearly state all periment details, and give perime Image: Clearly state all periment details, and give perime 13 Divide a to Complete Operations (Clearly state all periment details, and give perime Image: Clearly state all perime details, and give perime 14 Divide a to Complete Information (Clearly state all perime details, and give perime Image: Clearly state details, and give perime <	CE DRILLING OPNS. PLUG AND ABANDONMENT EST AND CEMENT JOB nu dates, including estimated date of starting any proposed ubing string. at 4575' and 4620' and remaining (2 SPF) on spiral phacing, and perform packer at 4600'. 00 gallons of 15% NEFE acid. Swab. ull RBP to 4625' and set same. Test 00 gallons of 15% NEFE acid. Swab. ower RBP to 4680' and pull packer (Ov v., Req. Affairs
ERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL EMPORARILY ABANDON CHANGE PLANS COMMENC ULL OR ALTER CASING CASING CASING T OTHER: Re-perforate and Stimulate COMMENC CASING T OTHER: OTHER: 12 Describe Proposed or Completed Operations (Clearly state all periment details, and give perimenwork) SEE RULE 1103. OTHER: 12 Distribution OTHER: OTHER: 13 Distribution Circulate hole clean. OTHER: 14 Distribution Circulate hole clean. OTHER: 15 Acidize perforated interval with premium charges the following: 4520'-4677' 185 total shots. 16 Unseat packer, lower same and retrieve RBP. Pr RBP to 1000 psi. Pull packer to 4350'. 17 Acidize perforated interval with a total of 50'. RE to 1000 psi. Pull packer to 4350'. 18 Unseat packer, lower same and retrieve RBP. Le back to 4350' and set same. Iberety certify that the information above in the formation above in	CE DRILLING OPNS. PLUG AND ABANDONMENT EST AND CEMENT JOB nu dates, including estimated date of starting any proposed abing string. at 4575' and 4620' and remaining (2 SPF) on spiral phacing, and perform packer at 4600'. 00 gallons of 15% NEFE acid. Swab. ull RBP to 4625' and set same. Test 00 gallons of 15% NEFE acid. Swab. ower RBP to 4680' and pull packer (Ov v., Reg. Affairs
ERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL EMPORARILY ABANDON CHANGE PLANS COMMENC ULL OR ALTER CASING CASING CASING T OTHER: Re-perforate and Stimulate COMMENC CASING T OTHER: OTHER: 12 Describe Proposed or Completed Operations (Clearly state all periment details, and give perimenwork) SEE RULE 1103. OTHER: 12 Distribution OTHER: OTHER: 13 Distribution Circulate hole clean. OTHER: 14 Distribution Circulate hole clean. OTHER: 15 Acidize perforated interval with premium charges the following: 4520'-4677' 185 total shots. 16 Unseat packer, lower same and retrieve RBP. Pr RBP to 1000 psi. Pull packer to 4350'. 17 Acidize perforated interval with a total of 50'. RE to 1000 psi. Pull packer to 4350'. 18 Unseat packer, lower same and retrieve RBP. Le back to 4350' and set same. Iberety certify that the information above in the formation above in	CE DRILLING OPNS. PLUG AND ABANDONMENT EST AND CEMENT JOB na dates, including estimated date of starting any proposed abing string. at 4575' and 4620' and remaining (2 SPF) on spiral phacing, and perform packer at 4600'. 00 gallons of 15% NEFE acid. Swab. ull RBP to 4625' and set same. Test 00 gallons of 15% NEFE acid. Swab. ower RBP to 4680' and pull packer (Ov

- B: If lower perfs are to be shut off, then:
- 8B. Unseat packer, lower same and retrieve RBP. POOH with RBP and packer. RBIH with bridge plug and packer. Set bridge plug at 4630' and test same to 1000 psi. Pull packer to 4350' and set same.
- Pump scale inhibitor squeeze down the tubing as follows: 9.
 - a.) Mix and pump 10 gallons TECHNI-HIB 430 with 20 bbls fresh water. b.) Pump 10 bbls fresh water.

 - c.) Mix and pump 1 drum TECHNI-HIB 757 and 10 bbls fresh water.
 - d.) Displace w/100 bbls fresh water.
- RIH with production tubing to 4670' (or 4600' if bridge plug was set). 10. ND BOP. RIH with rods and pump. RDMO DDU.
- 11. Return well back to production.

JECEINED

JUN 0 5 1994

---- INDBS Serie