

Jul 29 3 01 PM '68 O.C.C.

5a. Indicate Type of Lease State <u>01</u> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. NM 333

NEW MEXICO OIL CONSERVATION COMMISSION

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL <input type="checkbox"/> WELL GAS <input type="checkbox"/> WELL OTHER- <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator TEXAS PACIFIC OIL COMPANY	8. Farm or Lease Name State "AB"
3. Address of Operator P. O. Box 1069 - Hobbs, New Mexico	9. Well No. 1
4. Location of Well UNIT LETTER E , 1980 FEET FROM THE North LINE AND 660 FEET FROM THE West LINE, SECTION 36 TOWNSHIP 17-S RANGE 35-E NMMP.	10. Field and Pool, or Wildcat Vacuum Abo
15. Elevation (Show whether DF, RT, GR, etc.) 3894' GR	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Run open end tubing to 8709' and displace well fluids with mud laden fluid.
2. Spot 50 sax cement (8709-8334') over perms (Abo) 8409-8411'.
3. Pull tubing and shoot off 5-1/2" casing approximately 7110' (Top of cement by Temperature Survey).
4. Pull and lay down 5-1/2" casing.
5. Run 2" tubing and spot 25 sax cement at cut off (Approx. 7110').
6. Spot 25 sax cement at 6630' (Top of Glorietta).
7. Spot 25 sax cement at bottom of 8-5/8" intermediate casing at 4531'.
8. Spot 10 sax cement in 8-5/8" at surface.
9. Remove well head and install dry hole marker.
10. Fill cellar and clean location.

Verbal approval given by O.C.C. 7-29-68.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Original Signed by

SIGNED Sheldon Ward TITLE Area Superintendent DATE 7-29-68

APPROVED BY [Signature] TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: