

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
E-8570	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Water Injection Well		7. Unit Agreement Name Northeast Pearl Queen
2. Name of Operator Tamarack Petroleum Co., Inc.		8. Farm or Lease Name Northeast Pearl Queen
3. Address of Operator P. O. Box 2046, Midland, TX 79702		9. Well No. Unit 4
4. Location of Well UNIT LETTER P 330 FEET FROM THE south LINE AND 660 FEET FROM THE east LINE, SECTION 15 TOWNSHIP 19S RANGE 35E NMPM.		10. Field and Pool, or Wildcat Pearl (Queen)
15. Elevation (Show whether DF, RT, GR, etc.) 3798 KB		12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JQB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Move in and rig up plugging unit on/or about August 1, 1985.
2. Pull out of hole with tubing & packer.
3. Set CIBP at + 4900 (perfs 4946-4963), pump 5 sks cement on plug, and fill casing with 9.5# mud.
4. Cut 4 1/2 casing at + 3200 (B/salt 3157) and pull out and lay down
5. Pump 200' cement plug from 2950 to 3150. Tag plug
6. Pump 200' cement plug from 1875 to 1675 (T/anhydrite 1775)
7. Pump 100' cement plug from 215 to 115 (B/8 5/8" csg 165'). Tag plug
8. Set 10 sacks cement surface plug and marker
9. Clean location

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Randy A. McClay</u>	TITLE <u>Engineering Manager</u>	DATE <u>7/24/85</u>
ORIGINAL SIGNED BY <u>EDDIE SEAY</u> OIL & GAS INSPECTOR		
APPROVED BY _____	TITLE _____	DATE <u>JUL 26 1985</u>
CONDITIONS OF APPROVAL, IF ANY:		

RECEIVED
JUL 25 1985
U.S. DEPT. OF JUSTICE