

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
E-7360	

<p align="center">SUNDY NOTICES AND REPORTS ON WELLS</p> <p align="center"><small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</small></p>		
1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input checked="" type="checkbox"/> Water Injection Well	7. Unit Agreement Name	Northeast Pearl Queen
2. Name of Operator	8. Farm or Lease Name	Northeast Pearl Queen
3. Address of Operator	9. Well No.	Unit 1
P. O. Box 2046, Midland, TX 79702	10. Field and Pool, or Wildcat	Pearl (Queen)
4. Location of Well		
UNIT LETTER <u>K</u> , <u>1650</u> FEET FROM THE <u>South</u> LINE AND <u>1980</u> FEET FROM		
THE <u>West</u> LINE, SECTION <u>15</u> TOWNSHIP <u>19S</u> RANGE <u>35E</u> NMPM.		
15. Elevation (Show whether DF, RT, GR, etc.)	12. County	Lea
3779 KB		

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Move in and rig up plugging unit on/or about July 29, 1985.
2. Pull out of hole with tubing and packer.
3. Set CIBP at + 4800 (perfs 4862-5002 & open hole 5004 - 5016), pump 5 sks cement on plug, and fill casing with 9.5# mud.
4. Cut 4 1/2 casing at + 3200 (B/salt 3160) and pull out and lay down
5. Pump 200'cement plug from 3150 to 2950. Tag plug
6. Pump 200'cement plug from 1890 to 1690 (T/anhydrite 1790)
7. Pump 100'cement plug from 238 to 138 (B/8 5/8" casg 188'). Tag plug
8. Set 10 sacks cement surface plug and marker
9. Clean location

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Randy A. Mc Clay</u>	TITLE <u>Engineering Manager</u>	DATE <u>7/24/85</u>
APPROVED BY <u>ORIGINAL SIGNATURE OF JUDIE LEAY</u>	TITLE <u>OIL & GAS INSPECTOR</u>	DATE <u>JUL 26 1985</u>

CONDITIONS OF APPROVAL, IF ANY: