

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION

P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
B-4287	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT - A" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <u>Water Injection</u>		7. Unit Agreement Name
2. Name of Operator		8. Farm or Lease Name
TEXACO Inc.		West Lovington Unit
3. Address of Operator		9. Well No.
P. O. Box 728, Hobbs, New Mexico 88240		51
4. Location of Well		10. Field and Pool, or Wildcat
UNIT LETTER <u>F</u> , <u>1980</u> FEET FROM THE <u>North</u> LINE AND <u>1986</u> FEET FROM		Lovington
THE <u>West</u> LINE, SECTION <u>7</u> TOWNSHIP <u>17-S</u> RANGE <u>36-E</u> NMPM.		San Andres West
15. Elevation (Show whether DF, RT, GR, etc.)		12. County
3915' (DF)		Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data			
NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <u>Repair Waterflow</u> <input checked="" type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rig up. Install BOP. Pull tubing and packer.
2. Set RPB @ 4700' & spot 2 sx. sand on plug.
3. Perforate 5 1/2" csg @ approx 2000' W/2-JS.
4. Set cement retainer @ 50' above perforations.
5. Cement to surface W/525 sx. class 'H' cement. Squeeze W/addl. 200 sx. class 'H' Cement. WOC DOC. Test.
6. Pull RBP.
7. Run injection tubing and packer. Return to water injection.

THE STATE OF NEW MEXICO
OIL CONSERVATION DIVISION
SANTA FE, NEW MEXICO 87501

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED J. Sexton TITLE Asst. Dist. Mgr. DATE 11-3-82

APPROVED BY JERRY SEXTON TITLE DISTRICT SUPERVISOR DATE NOV 5 1982