

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease  
State ☒ Fee ☐

5. State Oil & Gas Lease No.  
**B-4129**

**SUNDARY NOTICES AND REPORTS ON WELLS**  
DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR RE-ENTERING CREEPS BACK TO A DIFFERENT RESERVOIR.  
SEE INSTRUCTIONS FOR REPORTS ON WELLS (C-103) FOR MORE INFORMATION.

1. ☒ OIL WELL ☐ GAS WELL ☐ OTHER-

2. Name of Operator  
**TEXACO Inc.**

3. Address of Operator  
**P. O. Box 728, Hobbs, New Mexico 88240**

4. Location of Well  
UNIT LETTER **D** ~~8~~ FEET FROM THE **North** LINE AND **660** FEET FROM  
THE **West** LINE, SECTION **8** TOWNSHIP **17-S** RANGE **36-E** N.M.P.M.

15. Elevation (Show whether DF, RT, GR, etc.)

7. Unit Agreement Name  
**West Lovington Unit**

8. Form of Lease Name  
**West Lovington Unit**

9. Well No.  
**43**

10. Field and Pool, or Wildcat  
**Lovington San Andres**

12. County  
**Lea**

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐

TEMPORARILY ABANDON ☐

PULL OR ALTER CASING ☐

OTHER ☐

PLUG AND ABANDON ☐

CHANGE PLANS ☐

REMEDIAL WORK ☐

COMMENCE DRILLING OPERATIONS ☐

CASING TEST AND CEMENT JOBS ☐

OTHER ☐


ALTERING CASING ☐

PLUG AND ABANDONMENT ☒

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

1. Rig up. Installed BOP.
2. Set cement retainer @ 4252'.
3. Pumped 300 sx Class 'C' Cement w/.5% CFR-2 & 5# salt per sx. into 5½" collapsed csg. Did not flow back. Left 30' cement on to of plug w/top of cement @ 4222'.
4. Cut 5½" csg. @ 2307'. Pulled 2307' (74 Jts.) 5½" 14# csg.
5. Set 120' plug (50 sx.) from 2307'-2187'.
6. Ran 8 5/8" cement retainer & set @ 1856'. Pump 100 sx Class 'C' cement below retainer. Left 30' cement on top of retainer w/top of cement @ 1826'.
7. Squeeze 100 sx Class 'C' Cement into 8 5/8" x 13 3/8" csg Annulus.
8. Set 270' Plug (80 sx.) Class 'C; Cement from 270'-Surface.
9. Install Dry Hole Marker, Clean Up.
10. Well P & A 6-7-76.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED 

TITLE **Asst. Dist. Supt.**

DATE **6-9-76**

APPROVED BY \_\_\_\_\_

TITLE \_\_\_\_\_

DATE **JUL 1 1976**

CONDITIONS OF APPROVAL, IF ANY: