

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION  
P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-73

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No. B-2411	

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT - 1" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Water Injection Well		7. Unit Agreement Name Lovington Paddock Unit
2. Name of Operator Texaco Producing Incorporated		8. Farm or Lease Name Lovington Paddock Unit
3. Address of Operator P.O. Box 728, Hobbs, New Mexico 88240		9. Well No. 68
4. Location of Well UNIT LETTER <u>K</u> , <u>1980</u> FEET FROM THE <u>South</u> LINE AND <u>1890</u> FEET FROM THE <u>West</u> LINE, SECTION <u>6</u> TOWNSHIP <u>17S</u> RANGE <u>37E</u> NMPM.		10. Field and Pool, or Wildcat Lovington Paddock
15. Elevation (Show whether DF, RT, GR, etc.) 3818 DF		12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. MIRU Install BOP. Pull tubing and packer.
2. GIH w/5½" CIBP on 2 7/8" workstring set @ 6100'.
3. Spot 10 sacks Class 'H' neat on CIBP.
4. Load hole with 9.5 ppg mud.
5. Spot 20<sup>22</sup> sacks Class 'H' neat from 4570-4670'.
6. Spot 55 sacks at the base of the salt and across the 8 5/8" casing shoe 2950-3208'.
7. Spot 20<sup>22</sup> sacks Class 'H' neat at the top of the salt 1933-2033'.
8. POH and lay down workstring.
9. Perforate 2 holes @ 350'.
10. Remove BOP. Install cap flange.
11. Pump 150 sacks Class 'H' neat down 5½" casing.
12. Remove casing head. Install dry hole marker. Clean location.

THE COMMISSION MUST BE ADVISED 24 HOURS PRIOR TO THE START OF ANY PRODUCTION OPERATIONS FOR THE WELL TO BE APPROVED.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Paul Kautz</u>	TITLE <u>Area Superintendent</u>	DATE <u>2-3-87</u>
397-3571		
APPROVED BY <u>Paul Kautz</u> Geologist	TITLE _____	DATE <u>Feb 2 1987</u>
CONDITIONS OF APPROVAL, IF ANY:		