

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input type="checkbox"/> Patent Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
7. Unit Agreement Name
8. Farm or Lease Name Rose Eaves "A"
9. Well No. #1
10. Field and Pool, or Wildcat Knowles Devonian
12. County Lea

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator Amerada Hess Corporation
3. Address of Operator 1209 South Main, Lovington, New Mexico
4. Location of Well UNIT LETTER B 660' FEET FROM THE North LINE AND 1980' FEET FROM East 2 TOWNSHIP 17-S RANGE 38-E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 3724' DF

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Rose Eaves "A" #1 - Run 5-1/2" Bridge Plug to 12,000' and set 35 sk plug on top of it, and fill csg with 10# Salt Water Mud. Find Free Point on 5-1/2" Csg. by stretch, 8700' top of cement, and cut 5-1/2" csg w/Jet Cutter. Set 35 sk plug @ 8700' or 5-1/2" cut off. Set 35 sk plug @ 5500', and set 35 sk plug @ 4816' and displace all plugs with 10# brine mud. Find Free Point and cut 8-5/8" csg. @ 2300' cement top or Free Point. Set 70 sk plug @ 1500' (Not @ 8-5/8" cutoff) and set 70 sk plug @ 270' and 10 sk plug @ surface and install Dry Hole Marker. The plugging operations on this well will start on about 12-26-72

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED W. A. Hamilton TITLE Area Superintendent DATE 12-16-72

APPROVED BY Joe D. Ramey TITLE Dist. I, Supv. DATE DEC 18 1972

COPIES OF APPROVAL, IF ANY:

RECEIVED

DEC 13 1972

OIL CONSERVATION COMMISSION
HOUSTON, TEXAS