

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION

P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO.	30-025-07302
5. Indicate Type of Lease	STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:
OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. Name of Operator
F&M Oil & Gas Company

3. Address of Operator
Box 891, Midland, Texas 79702

4. Well Location

Unit Letter K : 1980 Feet From The South Line and 1980 Feet From The West Line

Section 13 Township 17-S Range 38-E NMPM Lea County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

13-3/8" csg @ 297', circulated to surface
9-5/8" csg @ 4798', estimated TOC @ 981'
5-1/2" csg @ 12,110', estimated TOC @ 1450'
openhole completion 12,110-12,165'

- 1) Notify OCD prior to move in.
- 2) Set CIBP @ 12,050'. Circulate mud (10 ppg, 25#/bbl), pump 20 sx cmt 12,050-11,950'.
- 3) Pump 20 sx cmt 9000-8900'.
- 4) Pump 25 sx cmt 6000-5850'.
- 5) Cut & pull 5-1/2" csg at freepoint. Pump 40 sx cmt stub plug 50' in/out of stub. WOC & tag.
- 6) Perforate 9-5/8" csg @ 347', squeeze 70 sx cmt to 247'. WCC & tag @ 247'.
- 7) Pump 15 sx surface plug 30' to 3'.
- 8) Cut off wellhead, install dry hole marker, level pit & cellar, remove anchors. Leave location clear of trash.

*9 5/8 shoe plug 90 in. / 90 out
25 sx plug @ 2776'*

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE James F. Newman TITLE Engineer DATE August 22, 1997

TYPE OR PRINT NAME James F. Newman, P.E. 915-687-1994 TELEPHONE NO.

(This space for State Use)

Orig. Signed by:
Paul Kautz
Geologist

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY:

OCT 07 1997

THE OPERATIONS ON THIS WELL ARE BEING
CONDUCTED IN ACCORDANCE WITH THE
PERMITS AND OPERATING PLAN ON FILE
WITH THE OIL CONSERVATION DIVISION
AND ARE BEING APPROVED

dp