

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

<b>SUNDRY NOTICES AND REPORTS ON WELLS</b> <small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</small>		5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>		5. State Oil & Gas Lease No.
2. Name of Operator <b>John L. Hamon + 11/1/68</b>		7. Unit Agreement Name
3. Address of Operator <b>Box 663, Dallas, Texas 75221</b>		8. Farm or Lease Name <b>R.R. Cons</b>
4. Location of Well UNIT LETTER <b>M</b> , <b>660</b> FEET FROM THE <b>South</b> LINE AND <b>660</b> FEET FROM THE <b>West</b> LINE, SECTION <b>7</b> TOWNSHIP <b>17-S</b> RANGE <b>39-E</b> N.M.P.M.		9. Well No. <b>1</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>3674. GR</b>		10. Field and Pool, or Wildcat <b>South Knowles Devonian</b>
12. County <b>Lee</b>		

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/> CHANGE PLANS <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> CASING TEST AND CEMENT JOB <input type="checkbox"/> OTHER <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/> PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Pull rods & tubing. Set a permanent cast iron bridging plug at 12,050'. (Perforated at 12,125' to 12,204') Dump 2 sacks of cement on top of plug with dump bailer.
2. Shoot and pull 5-1/2" casing. (Should recover approximately 6000' of casing.)
3. Run tubing and set a 50 sack cement plug in and out of top of 5-1/2" stub through tubing.
4. Pull tubing up to base of 9-5/8" casing at 5001' and set a 50 sack cement plug from 5075' back to 4925' through tubing.
5. Pull tubing and set a 10 sack cement plug in top of 9-5/8" casing.

Work will begin upon approval of this report. The Commission will be notified prior to start of plugging operations.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Cecil H. Barton</u>	TITLE <u>Petroleum Engineer</u>	DATE <u>April 8, 1968</u>
APPROVED BY <u>[Signature]</u>	TITLE _____	DATE _____
CONDITIONS OF APPROVAL, IF ANY:		