

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Denver DD, Artesia, NM 88210

DISTRICT III
1000 Rio Branco Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-08455
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. B-2317
7. Lease Name or Unit Agreement Name M. E. Hale
8. Well No. 4
9. Pool name or Wildcat Vacuum (Grayburg/SA)

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER	
2. Name of Operator Phillips Petroleum Company	
3. Address of Operator 4001 Penbrook Street, Odessa, Texas 79762	
4. Well Location Unit Letter N : 660 Feet From The South Line and 1980 Feet From The West Line Section 35 Township 17-S Range 34-E NMPM Lea County	
10. Elevation (Show whether DP, RKB, RT, GR, etc.) 4029' RKB	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐
OTHER: Perforate 4415'-4421', acidize ☐
and return to production.

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. MI and RU DDU. COOH w/rods. Install BOP. COOH w/tubing.
2. RIH w/3-1/8" hollow carrier loaded with 12 gram charges loaded at 3 spf on 120 phasing. Perforate San Andres pay from 4415'-4421' (6'-18 shots).
3. RIH w/4-1/2" RBP and RTTS-type packer on 2-3/8" J-55 workstring. Set RBP +4445' and test. Dump 1 sack sand on RBP. Set packer +4400'. Swab perfs.
4. Pump 500 gals. 15% NEFE.
5. Swab back load water (Total = 30 bbls).
6. Wash sand off of RBP. COOH w/RBP and packer.
7. Rerun pumping equipment as before. Monitor fluid levels and production until well stabilizes.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

L. M. Sanders

TITLE

Supv., Reg/Proration

DATE

2-28-92

TYPE OR PRINT NAME

L. M. Sanders

TELEPHONE NO. 368-1488

(This space for State Use)

APPROVED BY

TITLE

DATE

MAR 04 '92

CONDITIONS OF APPROVAL, IF ANY: