

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION

P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

5a. Indicate Type of Lease
State ☒ Fee ☐

5. State Oil & Gas Lease No.
B-155

7. Unit Agreement Name

8. Farm or Lease Name

N. M. 'O' St. NCT-1

9. Well No.

13

10. Field and Pool, or Wildcat

Vacuum Glorieta

12. County

Lea

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE APPLICATION FOR PERMIT - C-101 FOR SUCH PROPOSALS.)

1. ☒ OIL WELL ☐ GAS WELL ☐ OTHER

2. Name of Operator
Texaco Inc.

3. Address of Operator
P. O. Box 728, Hobbs, New Mexico 88240

4. Location of Well
UNIT LETTER **N** **519** FEET FROM THE **South** LINE AND **1239** FEET FROM
THE **West** LINE, SECTION **36** TOWNSHIP **17-S** RANGE **34-E** N.M.P.M.

15. Elevation (Show whether DF, RT, GR, etc.)
3997' (GR)


16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER <u>Change Producing Strings using Present String as vent String</u> <input type="checkbox"/>			

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rig up. Pull rods & pump. Install BOP. Pull tubing. Test casing.
2. Acidize Glorieta perforations 5916'-6017' w/67,600 gals. 80 quality foamed acid system (6000 gals. 15% MOD-20 & 770,000 SCF-N₂) in 6 stages. Flush w/50,000 SCF-N₂.
3. Drill out cement plug in Abandoned Blinebry string @ 1500' & drill on plug from 5214'-6200'.
4. Perforate Blinebry string w/2-JSPF from 6004'-6014'.
5. Install pumping equipment over former Blinebry string & produce Glorieta formation. Former Glorieta string will be used as a vent string.
6. Test & return to production.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED  TITLE Asst. Dist. Supt. DATE 3/31/81

Orig. Signed By
Jerry Sexton

APPROVED BY  TITLE Dist. Supt. DATE APR 1 1981

CONDITIONS OF APPROVAL, IF ANY: