

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

3a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
3. State Oil & Gas Lease No.	
B-155	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator TEXACO Inc.		8. Farm or Lease Name N.M. '0" St. NCT-1
3. Address of Operator P. O. Box 728, Hobbs, New Mexico 88240		9. Well No. 23
4. Location of Well UNIT LETTER 0, 660 FEET FROM THE South LINE AND 1900 FEET FROM THE East LINE, SECTION 36 TOWNSHIP 17-S RANGE 34-E N.M.P.M.		10. Field and Pool, or Wildcat Vacuum Glorieta
15. Elevation (Show whether DF, RT, GR, etc.) 3990' (GR)		12. County Tea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	
		OTHER <u>Repair Water Flow</u> <input checked="" type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 103.

1. Rigged up. Pull rods & pump from Glorieta string. Install BOP. Pull tubing.
2. Set RBP in Blinbry string @ 4000' & test csg. Tested OK.
3. Set RBP in Glorieta string @ 4000' & test csg. Tested OK. Spot 20' on both plugs.
4. Perforate 2 7/8" Glorieta string & 8 5/8" csg w/2-shots @ 1545'.
5. Cement 11 3/4" x 8 5/8" csg annulus w/400 Sx. Class 'H' cement & 100 Sx. Class 'H' cement containing 2% CaCl. Cement circulated. Squeeze w/add'l 200 Sx. Class 'H' cement containing 2% CaCl. WOC. DOC. Test. Tested OK. Pull RBPs.
6. Install pumping equipment. Test & place on production. Compl. 6-22-81

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Asst. Dist. Mgr. DATE 6-25-81

APPROVED BY [Signature] TITLE DATE JUN 29 1981

CONDITIONS OF APPROVAL, IF ANY: