

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator <b>CONTINENTAL OIL COMPANY</b>	8. Farm or Lease Name <b>STATE H-35</b>
3. Address of Operator <b>Box 460, HOBBS, New Mexico 88240</b>	9. Well No. <b>7</b>
4. Location of Well UNIT LETTER <b>B</b> <b>660</b> FEET FROM THE <b>North</b> LINE AND <b>1780</b> FEET FROM THE <b>East</b> LINE, SECTION <b>35</b> TOWNSHIP <b>17-S</b> RANGE <b>34-E</b> NMPM.	10. Field and Pool, or Wildcat <b>Vacuum Abo, North</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>4056' DF</b>	12. County <b>Lea.</b>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐  
TEMPORARILY ABANDON ☐  
PULL OR ALTER CASING ☐

PLUG AND ABANDON ☐  
CHANGE PLANS ☐

OTHER **Repair Surface Water Flow** ☒

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐  
COMMENCE DRILLING OPNS. ☐  
CASING TEST AND CEMENT JOBS ☐  
OTHER ☐

ALTERING CASING ☐  
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

IT IS Proposed to Repair the Surface Water Flows Follows:  
Run Free Point, cut & Pull 7" OD CSG AT  $\pm$  4800'. Load  
Hole with 10 PPG Brine & Set CIBP IN 9 5/8" CSG  $\pm$  20' Above  
Cut off 7' CSG and Spot 10' cmt on top. Perf w/ 2 JSPE 1200-1202'.  
Cmt Squeeze w/ 600 SX Thix-set cmt & Follow w/ 400 SX class "C"  
Cmt with Additives. Drill out cmt & Pressure Test to 700 PSI.  
Run Cement Bond Log & Shut well in. Save well bore  
For Future Use.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED **Bill Penlow** TITLE **adm Supervisor** DATE **9-17-76**

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE **SEP 20 1976**

CONDITIONS OF APPROVAL, IF ANY:

**NMOCC-5, File**

RECEIVED

FEB 2 1976

GIL CONSERVATION COMM.  
HOBBS, N. M.