

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

## SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		7. Unit Agreement Name
2. Name of Operator <b>EXXON CORPORATION</b>		8. Farm or Lease Name <b>CHARLES S. ALVES</b>
3. Address of Operator <b>P.O. BOX 1600, MIDLAND, TEXAS 79701</b>		9. Well No. <b>2</b>
4. Location of Well UNIT LETTER <b>C</b> <b>520</b> FEET FROM THE <b>NORTH</b> LINE AND <b>2120</b> FEET FROM THE <b>WEST</b> LINE, SECTION <b>7</b> TOWNSHIP <b>19-S</b> RANGE <b>35-E</b> NMPM.		10. Field and Pool, or Wildcat <b>SCHARB BONE SPRINGS</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>3906 RDB</b>		12. County <b>LEA</b>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <b>REPAIR CSG. LEAK</b> <input checked="" type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

RUN 2 7/8" LINER WITH 3 1/2" BIT. CEMENT FIRST STAGE W/160 SX CLASS H CEMENT. DISPLACE W/FRESH WTR. WDC 8 HRS. AND RUN SURFACE TEMP. SURVEY FOR CEMENT TOP. TOP EST. TO BE 6000'.  
PERFORATE 2 HOLES ABOVE CEMENT TOP.  
PICK UP 1 1/2" TBC. STRING AND DRILL OUT CEMENT ACROSS PERF. HOLE AND TEST 2 7/8" CSG.  
RUN CORRELATION LOG AND PERF. 10109-10114, 6 SHOTS AND 10134-10142, 9 SHOTS.  
RUN 1 1/2" TBC W/TREATING PKR. TO BOTTOM OF LOWER PERF. ACIDIZE PERF. INTERVALS W/5000 GALS OF 15% HCL CONTAINING 5 GALS OF COREXIT  
PULL TBC AND PACKER  
RUN 1 1/2" TBC. WITH ANCHOR AND SEATING NIPPLE.  
RUN CONROD AND PUT WELL ON PRODUCTION

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *Samuel* TITLE UNIT HEAD DATE 1-4-74

APPROVED BY *Orig. Signed by* TITLE  DATE

CONDITIONS OF APPROVAL, IF ANY: