

COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
A-1320

<b>SUNDRY NOTICES AND REPORTS ON WELLS</b> (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)		
OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name	
Name of Operator	8. Farm or Lease Name	
EXXON CORPORATION	NEW MEXICO "K" STATE	
Address of Operator	9. Well No.	
P.O. Box 1600, MIDLAND, TEXAS 79701	29	
Location of Well	10. Field and Pool, or Wildcat	
UNIT LETTER K 2310 FEET FROM THE SOUTH LINE AND 1981 FEET FROM THE WEST LINE, SECTION 28 TOWNSHIP 17-S RANGE 35-E NMPM.	VACUUM GLORIETA	
15. Elevation (Show whether DF, RT, GR, etc.)	12. County	
3957 D.F.	LEA	

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data			
NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>		CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER PERFORATE AND STIMULATE <input checked="" type="checkbox"/>		OTHER <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

PULL RODS & TBG. PERFORATE THE INTERVALS 6112-6116', 6130-6135', 6141-6145' AND 6153-6162' WITH 1 SHOT PER FT. USING A JET. CSG. GUN W/PREMIUM CHARGE. USE LUBRICATOR WHEN PERFORATING. RUN TREATING PKR. ON WORKSTRING. SPOT ACID FROM 6170-6080'. SET PACKER AT 6080'. ACIDIZE PERFORATIONS W/6500 GALS. 15% HCL CONTAINING 6 GALS COREXIT 7652. PUMP AS FOLLOWS: 1500 GALS. ACID, 400# SLUG OF DIVERTER CONTAINING 200# BENZOIC ACID FLAKES, 200# ROCK SALT AND 15# GUM KARAYAM BLENDED INTO 7 BBLs. CLEAN BRINE. 5000 GALS. ACID. 23 BBLs CLEAN BRINE. DISPLACE ACID INTO FORMATION AT 2-3 BPM RATE NOT TO EXCEED 1200 PSI SURFACE PRESSURE. PULL PACKER. RUN SUBSURFACE PRODUCTION EQUIPMENT AND PUT WELL ON PUMP.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Melba Whipling</u>	TITLE <u>UNIT HEAD</u>	DATE <u>4-13-76</u>
APPROVED BY <u>[Signature]</u>	TITLE <u></u>	DATE <u></u>

CONDITIONS OF APPROVAL, IF ANY:

APR 16 1976