

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
E-7586	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER		7. Unit Agreement Name
2. Name of Operator Lone Star Producing Company		8. Farm or Lease Name Gulf State
3. Address of Operator Box 4815, Midland, Texas 79701		9. Well No. 1
4. Location of Well UNIT LETTER M 330 FEET FROM THE South LINE AND 330 FEET FROM THE West LINE, SECTION 30 TOWNSHIP 17S RANGE 36E N.M.P.M.		10. Field and Pool, or Wildcat South Double A-Abo
15. Elevation (Show whether DF, RT, GR, etc.) 3,882' DF		12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPER. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Plug and abandonment procedure:

- Step No. 1 - Set permanent bridge plug on wire line at 8,650'. Place two (2) sacks cement on top of plug with dump bailer.
- Step No. 2 - Load hole with mud laden fluid.
- Step No. 3 - Spot 35 sack cement plug from 3,650' up to 3,550' (bottom of 7-5/8" intermediate casing at 3,600').
- Step No. 4 - Spot 40 sack plug in and out of bottom of 10-3/4" casing at 395' from 375' up to 365'.
- Step No. 5 - Place 15 sack plug in top of 10-3/4" surface casing.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED C. R. Ramsey TITLE Dist. Prod. Supt. DATE September 16, 1968

APPROVED BY Leslie A. Clements TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: