

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-

5a. Indicate Type of Lease

State ☒ Fee ☐

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator SHELL OIL COMPANY	8. Farm or Lease Name STATE "B"
3. Address of Operator P. O. BOX 991, HOUSTON, TEXAS 77001	9. Well No. 4
4. Location of Well UNIT LETTER <u>P</u> <u>660</u> FEET FROM THE <u>SOUTH</u> LINE AND <u>990</u> FEET FROM THE <u>EAST</u> LINE, SECTION <u>30</u> TOWNSHIP <u>17-S</u> RANGE <u>35-E</u> NMPM.	10. Field and Pool, or Wildcat VACUUM (GLORIETA)
15. Elevation (Show whether DF, RT, GR, etc.) 3896' DF	12. County LEA

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input checked="" type="checkbox"/> *	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	
OTHER *CEMENT TO SURFACE: OPEN ADDITIONAL PAY <input checked="" type="checkbox"/> AND ACIDIZE			

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work): SEE RULE 1103.

* PER NEW MEXICO OIL CONSERVATION DIVISION REQUEST.

- Clean out to 6175' (PBDT). Set RBP @ 6100' \pm and spot 15' of sand on top. Pressure test casing to 500 psi.
- Run CBL/VDL/CCL/GR log from 6085' \pm to surface. Perforate \pm 50' above TOC. Set cmt retainer \pm 150' above squeeze holes.
- Pump \pm 2000 sx light cmt w/8#/sx salt, followed by \pm 300 sx Class "C" w/2% CaCl₂. Circ to surface. Reverse out excess. WOC 24 hrs.
- Drill out cmt retainer and cmt. Reverse sand off bridge plug. (Proceed w/plans to open additional pay and acidize).
- Spot 250 gals 15% HCl across zone to be perf'd. Perforate Glorieta 6064' to 6096' (14 holes).
- Acidize perms w/4600 gals 15% HCl-NEA.
- Return well to production.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Jerry Sexton A. J. FORE TITLE SUPERVISOR REG. & PERMITTING DATE AUGUST 5, 1982

ORIGINAL SIGNED BY

APPROVED BY JERRY SEXTON
CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE AUG 9 1982

RECEIVED

AUG 9 1982

ADDS OFFICE