

NO. OF COPIES RECEIVED	
DISTRIBUTION	
DATE	
FILE	
S.G.S.	
AND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5-NMOCC
1-W.A. Frnka-Tulsa
1-R.W. Blohm-Midland
1-Engr.
1-File

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDY NOTICES AND REPORTS ON WELLS
DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO RE-OPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE APPLICATION FOR PERMIT TO DRILL (FORM C-101) FOR SUCH PROPOSALS.

OIL WELL <input type="checkbox"/>	GAS WELL <input type="checkbox"/>	OTHER <input type="checkbox"/>
-----------------------------------	-----------------------------------	--------------------------------

Name of Operator
Getty Oil Company
Address of Operator
P. O. Box 730, Hobbs, New Mexico 88240

7. Unit Agreement Name
8. Farm or Lease Name Skelly P State
9. Well No. 3

Location of Well
UNIT LETTER C 779 FEET FROM THE North LINE AND 2285 FEET FROM
THE West LINE, SECTION 33 TOWNSHIP 17-S RANGE 35-E N.M.P.M.

10. Field and Pool, or Wildcat Glorieta
--

11. Elevation (Show whether DF, RT, GR, etc.)
3951' KB

12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
ULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER <u>squeeze off water flow</u> <input type="checkbox"/>		OTHER <input type="checkbox"/>	

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

SKELLY P STATE
WELL #3

WORK OVER PROCEDURE

1. Rig up pulling unit.
2. Install BOP.
3. Pull out of hole w/rods and tubing.
4. Run in hole w/noise log and locate flow.
5. Run in hole w/bridge plug and set at $\pm 100'$ below fluid entry from noise log.
6. Dump 30' of sand on bridge plug.
7. Run in hole tubing and packer and set $\pm 100'$ above perfs.
8. Run in hole w/tubing gun and perforate across from flow.
9. Cement as recommended by Western.
10. WOC
11. Drill out cement
12. Run tubing and rods.
13. Place well on production.

I, I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Dale Crockett</u>	TITLE <u>Area Superintendent</u>	DATE <u>January 27, 1981</u>
ORIG. SIGNED BY <u>Jerry Sexton</u>	TITLE <u>Dist. L. Supv.</u>	DATE <u>FEB 13 1981</u>
APPROVED BY <u></u>	TITLE <u></u>	DATE <u></u>

CONDITIONS OF APPROVAL, IF ANY: