

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION

P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease
State ☒ Fee ☐
5. State Oil & Gas Lease No.
F-1565

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT - " (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-	7. Unit Agreement Name
2. Name of Operator Getty Oil Company	8. Farm or Lease Name State 'BA'
3. Address of Operator P. O. Box 728, Hobbs, New Mexico 88240	9. Well No. 9
4. Location of Well UNIT LETTER <u>B</u> <u>660</u> FEET FROM THE <u>North</u> LINE AND <u>2310</u> FEET FROM THE <u>East</u> LINE, SECTION <u>36</u> TOWNSHIP <u>17-S</u> RANGE <u>34-E</u> NMPM.	10. Field and Pool, or Wildcat Vacuum Blinebry & Glorieta
15. Elevation (Show whether DF, RT, CR, etc.) 4005' (DF)	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>		CASING TEST AND CEMENT JOBS <input type="checkbox"/>	
OTHER <u>Abandon Blinebry -Complete as Single</u>		OTHER <input type="checkbox"/>	

in Glorieta. Squeeze old San Andres Perfs.

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1503.

1. Rig up. Install BOP. Pull rods & pump from East String.
2. Set CIBP in East String @ 6350' & dump 30' Cement on plug. Abandon Blinebry perfs. Set 2nd CIBP @ 5000' & spot 30' sand on plug.
3. Squeeze csg. leak in San Andres (West string) & San Andres perfs in East string W/100 sx. Class H Cement. WOC. DOC. TEST. Abandon San Andres Zone.
4. Drill out CIBP @ 5000' & Clean out to 6300.
5. Set pkr. in East String @ 5916'. Acidize Glorieta perfs. 6016-6186' W/3000 gals 20% NEFE HCL Acid.
6. Install pumping equipment in East String.
7. Clean out West String to 6048' & use as vent string.
8. Test & place on production.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED W.B. Calk TITLE Dist. Opr. Mgr. DATE 2-20-85

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT 1 SUPERVISOR

APPROVED BY _____ TITLE _____ DATE FEB 27 1985

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

FEB 20 1985

U.S. DEPT. OF JUSTICE
FEDERAL BUREAU OF INVESTIGATION